Acrylic Clawfoot



Read the instructions below and follow all local plumbing and building codes.

Unpack and inspect your new feet for any shipping damages and ensure no pieces are missing.

If any damages are discovered DO NOT INSTALL.

Before installing it is suggested to have a blanket or soft surface to avoid scratches while the tub is turned upside down while attaching the feet.

TOOLS AND MATERIALS NEEDED:

(2) Brackets (4) Bolts (8) Washers (8) Nuts (4)Clawfeet

17mm & 19mm Sockets | Socket Wrench

- 1. While the tub is upside down, take off the plastic caps at each foot location covering screw threads. There will be 1 washer and 1 nut underneath the plastic caps. Take each of these off.
- 2. Place a bracket down so that two screws are protuding from the 2 elongated holes in the bracket and center the bracket evenly.
- 3. Thread the washer and nut down on both ends of the bracket but only hand tighten these for now.
- 4. Taking one of the clawfeet, line the threaded hole in the bracket up with the hole on the back of the leg and ensure that it will fit properly. The bracket can be adjusted slightly if needed.
- 5. When you've made sure the bracket is in the proper postion for the installation, tighten down both nuts with a 19mm socket.












STEPS CONTINUED

6. Supplied is a washer and bolt for each leg. Place 1 washer on a nut, this will be needed in later steps.



8. Take the nut with a washer on it that was prepared in the steps previously and hand tighten the leg down.

(Be sure the leg fits properly and is level before continuing)



REPEAT STEPS 1-5 FOR THE REMAINING BRACKET

REPEAT STEPS 6-9 FOR EACH REMAINING CLAWFOOT

NOTE: EACH LEG HAS AN ADJUSTABLE LEVELER FOR ANY ADJUSTMENTS NEEDED. THE NUT TO MAKE THE ADJUSTMENTS IS 17MM.











