

10ft Cattle Squeeze Chute With Scale










**⚠ WARNING**







- Please read and understand the product manual completely before assembly
- Check against the parts list to make sure all parts are received
- Wear proper safety goggles or other protective gears while in assembly
- Do not return the product to dealer. They are not equipped to handle your requests.

Missing parts or have questions on assembly?


Please call: 1-877-761-2819 or email: cs@tmgindustrial.com

TMG-CSC11 Part List(Picture 1)




















Parts Code	Graphical	Description	Quantity
1		Pull rod movable door	1
2		Side panel B	1
3		Side panel A (Logo)	1
4		Pull rod sliding back door	1
5		Anti-reverse tool	1
6		Body clamping handle assembly	1
7		Load-weighting chassis	1
8		Pull rod sliding door-the erecting rod	1
9		Main body "L" connecting pin	4

10		M8*35 bolts	4
11		M8 nuts	4
12		Junction box	1
13		Data line	1
14		Monitor	1
15		Sensors & gimbals	4

(Picture 1)




1-Pull rod movable door(Picture 1)












Parts Code	Graphical	Description	Quantity
1-1		Door Frame	1
1-2		Slide Door Panel (L)	1
1-3		Slide Door Panel (R)	1
1-4		Center Rotary Bar	1
1-5		Drop-Up Rod	1
1-6		M10 Nut	13
1-7		Roller	8
1-8		M10*90 Bolt	1
1-9		M8*30 Bolt	1
1-10		M10*80 Bolt	7
1-11		M8*40 Bolt	1
1-12		Gear	1
1-13		Limit Block	1
1-14		Drop-Down Rod	1
1-15		Arresting Lever	1
1-16		Wire Spring	1
1-17		M8 Nut	2
1-18		Handle Brake	1
1-19		M10*35 Bolt	3



1-20		M20 Nut	1
1-21		M10*45 Bolt	2

(Picture 2)




2-Side panel B (Picture 3)













Parts Code	Graphical	Description	Quantity
2-1		Outer Frame B	1
2-2		Inner Frame B	1
2-3		Access Door	1
2-4		Upper Side Door	1
2-5		Bottom Side Door	1
2-6		P-Lock	3
2-7		Arresting Stop	5
2-8		M10*35 Bolt	5
2-9		M10 Nut	5
2-10		Connecting Pin	2
2-11		Cotter Pin	8






2-12		M8*40 Bolt	2
2-13		M8 Nut	2

(Picture 3)




3-Side panel A(Logo)(Picture4)












Parts Code	Graphical	Description	Quantity
3-1		Outer Frame A	1
3-2		Inner Frame A	1
3-3		Entrance Gate	1
3-4		Anti-Kick Door	1
3-5		Upper Side Door	1
3-6		Bottom Side Door	1
3-7		P-Lock	3
3-8		Anti-Kick door handle	1
3-9		Wire Spring	1
3-10		Arresting Stop	5
3-11		M10*35 Bolt	5
3-12		M10 Nut	7



3-13		M10*25 Bolt	1
3-14		Cotter Pin	10
3-15		Connecting Pin	2
3-16		M8*40 Bolt	2
3-17		M8 Nut	2

(Picture 4)




4-Pull rod sliding back door (Picture 5)















Parts Code	Graphical	Description	Quantity
4-1		Door Frame	1
4-2		Slide Door Panel (L)	1
4-3		Slide Door Panel (R)	1
4-4		Roller	8
4-5		Inter pull Rod	1
4-6		M10*50 Bolt	1
4-7		M10 Flat Washer	2
4-8		Rolling Bearing	1
4-9		M10*80 Bolt	2
4-10		M10*90 Bolt	2
4-11		M10 Nut	10






4-12		Outer Pull Rod	1
4-13		Door Locker	1

(Picture 5)




6-Body clamping handle assembly(Picture 6)

Parts Code	Graphical	Description	Quantity
6-1		Front Fixed Seat	1
6-2		Limit Block	1
6-3		Gear	1
6-4		Handle	1
6-5		Arresting Lever	1
6-6		Wire Spring	1
6-7		Handle Brake	1
6-8		M8*40 Bolt	1
6-9		M8*30 Bolt	1
6-10		M8 Nut	2
6-11		M10*45 Bolt	2
6-12		M10 Nut	14
6-13		M20 Nut	1
6-14		M10*35 Bolt	4

6-15		Upper Rod	1
6-16		Lower Rod	1
6-17		U-bolt	6
6-18		Fixed Rod	1
6-19		Fixed Seat	1


(Picture 6)



Installation steps 1

Select a flat ground, first put both the front and back doors, and the distance between the two fixed plates is 2538mm.


Notice: Please prefix the two sliding doors with wire and piles to prevent them from falling and injuring people.



Installation steps 2


Place the wired seat on the limit board of the two sliding doors. Place the sensor gimbal anchor (already installed on the load-weighting chassis) into the limit board of the load-bearing seat (already installed on the front and back sliding doors)

Notice: Please pay attention to your fingers and installed data lines when you install the load-weighting chassis




Installation steps 3

Connect bottom of the two side panels with the fixed plates of the front and back doors by using "L" pin, and a total of four pins are used. Four bolts and nuts are used to install top of the main frame.




Installation steps 4

Connect the installed body clamping handle assembly on the top horizontal tube of the two sides panel by using three U-bolts and plates.



Installation steps 5

Insert the data line and hang the monitor on the side panel



BEFORE WORKING WITH ANIMALS, SAFETY CHECK:

All parts have been reinstalled correctly

All chute functions, including the head gate and squeeze mechanisms, are working properly

Installation

