









Key	Component	Qty
	A Bleeding Valve Key	1
	B Bleeding Valve 1/2 "	1
	D Friction Cups/Cushions	4
	E Upper Bracket	2
	F Lower Bracket	2
	G Screw-5,5x45mm	8
	H Wall Plug	8



**Assembly Instructions**

Fit bleending valve (B) & blind tap (C).

Use Carisa bleeding valve key (A) to turn bleeding valve (B).


Accurately mark out bracket holes on wall using spirit level.


Drill four 8mm diameter holes for upper brackets (E) and four 8mm diameter holes for bottom brackets(F).






Friction cups (D) **MUST** be fitted to each mounting brackets (E,F) to suppress potential noise.


Screw brackets (E,F) into wall plugs (H) with 5,5mm diameter x 45mm screws (G).

Hang radiator by sliding the bosses on the back of the radiator into brackets (E,F).





Key	Component	Qty
	<b>A</b> Bleeding Valve Key	1
	<b>B</b> Bleeding Valve 1/2 "	1
	<b>C</b> Bracket	2
	<b>D</b> Screw-5,5x45mm	4
	<b>E</b> Wall Plug	4



**Assembly Instructions**

Accurately mark out bracket holes on wall using spirit level. (Attention for pear shaped holes)

Drill 2x2 (four) holes 8mm diameter for upper and bottom brackets (B) which have been already mounted on radiator.

Place the wall plugs (D) into the holes on the wall and then drive the screws (C) into the wall plugs. Keep a little distance between screw head and wall to hang the radiator using with screw head.

Hang the radiator from pear shaped holes on bracket through to the screw head.