


Key	Component	Qty
	A Bleeding Valve Key	1
	B Bleeding Valve 1/2 "	1
	C M10 Stud	4
	D Spring Washers	4
	E M10 Nuts	4
	F Product Bracket	4
	G Wall Bracket	4
	H Screw-5x16mm	4
	I Screw-5,5x45mm	4
	J Wall Plug	4



Assembly Instructions

- Use Carisa bleeding valve key (A) to turn bleeding valve (B).
- Accurately mark out bracket holes on wall using spirit level. (Using wall bracket (G))
- Drill (2x2) 4 8mm holes for two wall bracket (G).
- Place 4 wall plugs (J) into the hole and screw wall brackets (G) with 5,5x45 mm screws (I).
- Assemble the M10 studs (C) into the M10 nuts which are welded over radiator by hand or allen key.
- Fit the Product bracket (F) by centering the assembled studs on the back of radiator.
- Fix the product bracket using with Spring washers (D) and M10 Nuts (E).
- Hang the radiator by engaging each other product bracket and wall bracket.
- Fix the engaged brackets with the Screw-5,5\*16mm (H) after setting wall distance.