

# ActionFit Traditional

## UP252 HIGH JUMP

PARTS LIST		
DESCRIPTION	QTY	PART NUMBER
UPRIGHT 120" LG	1	GR98M4
UPRIGHT 144" LG	1	GR98M5
HIGH JUMP BAR	1	202129
HARDWARE COMPLETE	1	403967
3/8" x 1 1/4" B.H.C.S.	4	811051*
3/8" LOCK WASHER	4	817334*
USAGE/WARNING LABEL	1	403860*

*Unless Otherwise Specified, All Units of Measure are Each*

*\*Items listed below Hardware Complete line are included with Hardware Complete Number*

**Warning: During Installation, Hardware And Small Parts Are Choking Hazards For Young Children. Store Unused Parts Appropriately Until Assembly Is Completed. Once Assembly Is Completed, Remove Any Unused Parts From The Play Environment And Dispose/Save Them In A Secure Location.**

**Note: Peen Tee-Nuts and Flatwashers to match radius of pipe after assembly is complete.**

**Note: Loctite (supplied by others) should be used on any non-patch hardware.**

### **SPECIFICATIONS:**

**UPRIGHTS:** Shall be fabricated of 3-1/2" O.D. (13 gauge) galvanized pipe, cast aluminum cap, self-sealing pop rivets and 3/8" inserts.

**HIGH JUMP BAR:** Shall be an all-welded construction fabricated of 1-5/16" O.D. galvanized pipe and 1/4" x 2-1/2" H.R. steel mounting plates.

**FINISH:** Uprights and high jump bar shall all have a powder coat finish.

### **INSTALLATION INSTRUCTIONS:**


1. Before starting assembly, review the General Installation Instructions at the beginning of this Installation Guide and the Typical Assembly Details in the back.
2. Dig footings for the two uprights. Maintain footing spacing, size and depth as indicated on the Plan View and Elevation View. Allow for depth of desired Finished Surface.
3. Position uprights in footings. Attach High Jump Bar to uprights using 3/8" x 1 1/4" B.H.C.S, 3/8" Lockwasher and 3/8" Flatwasher. See Detail 332. Align, plumb, and brace in place. Pour concrete as shown on Plan View and Elevation View. Be sure to hold top of concrete footing 0'-10" [25.40cm] down from the Finished Surface. Slope top of concrete for proper drainage.
4. Allow concrete a minimum of 48 hours to cure and harden before using High Jump Station.

# ActionFit Traditional

## UP252 HIGH JUMP

### MAINTENANCE PROCEDURE:

Periodically check hardware for tightness, and tighten as necessary. Always check all parts for breakage or wear, and immediately put equipment out of service until any faulty parts found are repaired or replaced. Check for rust or paint loss and touch-up if necessary with paint. Check welded areas and verify integrity. Check periodically resilient surfacing for appropriate depth and remove extraneous materials that could cause injury, infection, or disease. Maintain detailed installation, inspection, maintenance, and repair records for each public-use playground equipment.



 = INSTALLATION DETAIL

**FINISHED ASSEMBLY**

Issued/Revised: 9/28/2016




800.458.5872

www.actionfitoutdoors.com


# ActionFit Traditional

## UP252 HIGH JUMP



**PLAN VIEW**

**CONCRETE REQUIRED:**  
.218 CUBIC YARDS  
[.166 CUBIC METERS]




**ELEVATION VIEW**

Issued/Revised: 9/28/2016




800.458.5872

www.actionfitoutdoors.com



## UP252 HIGH JUMP



332