

Warranty

This product is warranted to the retail customer for 90 days from date of retail purchase, against defects in material and workmanship.

WHAT IS COVERED

- Replacement parts and labor.
- Transportation charges to customer for the repaired product.

WHAT IS NOT COVERED

- Damage caused by abuse, accident, misuse, or neglect.
- Transportation of the unit or component from the customer to the Master Service Center.

IMPLIED WARRANTIES

Any implied warranties, including the implied warranty of merchantability are also limited to the duration of 90 days from the date of retail purchase.

WARRANTY REGISTRATION

Register on-line at www.koolatron.com AND keep the original, dated, sales receipt with this manual.

WARRANTY AND SERVICE PROCEDURE

If you have a problem with your unit, or require replacement parts, please telephone the following number for assistance:

North America 1-800-265-8456

Master Service Centers are at these locations:

U.S.A.
4330 Commerce Dr.
Batavia, NY 14020-4102

Canada
139 Copernicus Blvd.
Brantford, ON N3P 1N4

A Master Service Center must perform all warranty work



CRUISER THERMOELECTRIC COOLER



CORC24
Owner's Manual



www.koolatron.com

©2015 Koolatron, Inc. All rights reserved.
All specifications are subject to change without notice.

Made in China

H1S181

01/2015-v1

Relax Responsibly.® Corona Extra® Beer.
Imported by Crown Imports, Chicago, IL
Officially licensed by Marcas Modelo S.A. de C.V.
ALL RIGHTS RESERVED.

THIS ITEM IS INTENDED FOR PEOPLE OF LEGAL DRINKING AGE

FEATURES

- Employs thermoelectric technology using the latest Peltier devices.
- Environmentally friendly. Does not contain any CFC's or polluting coolants.
- High performance with low power draw. Cools to approximately 40F°/22C° below outside temperature.
- Reliable and virtually wear free. Apart from the fan, the thermoelectric cooling unit does not have any moving parts.
- Featuring lime storage compartment inside the lid (see picture below).
- Included are: Koolatron PowerPack which permits use of cooler in your house or hotel, from any 110/120 volt AC wall outlet.



OPERATING INSTRUCTIONS

- Just plug your cooler into the 12 volt cigarette lighter receptacle in your vehicle. The current consumed is about 4.5 amps. When your vehicle is running and the electrical system is operating properly, your cooler will operate continuously without discharging the battery. When the battery is not being charged, the cooler should not be operated for more than 4 hours.
- The cooler can be operated continuously from a 110/120 volt AC wall outlet using the included Koolatron Power Pack.
- For best results, precool your unit and the food and beverages before placing them in your cooler. If the cooler is loaded with warm material, it will require at least 12 hours to cool the contents.

MAINTENANCE

- Keep cords and cigarette lighter sockets clean at all times. Small tobacco or dirt particles in the socket or the plug may affect performance.
- The motor, fan and control panel vents should be cleaned periodically. While the unit is unplugged, clean the fan blades and motor shaft using a paint brush or other soft bristled brush. Remove all hair, dirt, or dust that may have accumulated.
- To clean, wipe the inside with a warm damp cloth or sponge. Do not use harsh or abrasive cleaners. A mild soap should be sufficient, but if stains or odors remain, household bleach or baking soda may be added to the washing solution. Keep the lid open for several hours after cleaning to allow the interior to thoroughly dry and to prevent odors from forming in the cooler.
- For long periods of storage, a small container of baking soda or charcoal, placed inside, will eliminate objectionable odors.

PRECAUTIONS

- The cooler is designed to operate on 12 volts direct current only. Do not attempt to connect the cooler directly to 110/120 volt AC wall socket without using the Koolatron Power Pack.
- Do not use the cooler with any other AC adapter device other than the Koolatron Power Pack. Failure to do so may invalidate warranty and pose a hazard.
- Do not operate the cooler in direct sunlight or in hot enclosed areas such as automobile trunks. The cooler generates heat and must have free air circulation to perform properly.
- Do not block the ventilation area of the control panel. Free flow of air is necessary for effective heat transfer. Regularly check the panel for dirty or clogged vents.
- Ensure that the cigarette lighter socket is clean and safeguarded by a correctly fused circuit.
- Push the plug firmly into the lighter socket to ensure good contact.

ACCESSORIES

For prices and availability, please call: 800-265-8456



12V Power Cord



Battery Saver