

PART NUMBER 00-11047

## INSTALLATION INSTRUCTIONS

This Nitrous Outlet Vehicle Specific Dashboard Cubby Switch Panel is designed specifically for the 2007-2014 Chevrolet & GMC Full Size Pickup. If you need any assistance during installation or if you have questions about this harness, call our Tech Help Line at (254) 848- 4300.

### Tools Needed for Installation\*:

- 1" Hole Saw Drill Body Tool
- 7/16" Wrench

\*These are the tools required for installation of this kit on a stock vehicle. If your vehicle has aftermarket parts, other tools may be required.



## Step 1:

Using a body tool, remove the center dashboard panel. Disconnect the 12v plug and accessory wires from the back of the panel.



#### Step 2: Remove the

Remove the rubber insert from the passenger side cubby hole.



### Step 3:

Route the wires for the switch panel from the main harness to the back side of the dashboard.

IMPORTANT- ALL APPROPRIATE SAFETY EQUIPMENT (GLOVES, TOOLS ETC.) MUST BE USED DURING THE INSTALLATION OF THIS PRODUCT(S). NITRO DAVE'S LLC ACCEPTS NO RESPONSIBILITY FOR INJURIES RESULTING IN THE INSTALLATION OF ANY PRODUCT(S). NITROUS OXIDE IS FOR OFF-ROAD USE ONLY.



PART NUMBER 00-11047

## INSTALLATION INSTRUCTIONS



### Step 4:

Using a 1" hole saw, drill a hole in the back of the passenger side cubby of the center dashboard panel.




### Step 5:

Route the switch panel wires through the dashboard panel and connect them to the switch panel using the diagram provided.

### Step 6:

Before bolting the panel into place test the system and make sure your wiring is correct. With the key in the on position turn on system arm, the solenoids should click. If they don't something is wired wrong. If they do click then turn on the heater and see if it gets warm, then try your purge. Once everything is working correctly move to the next step.



### Step 7:

Using a 7/16" wrench, bolt the switch panel in place.

IMPORTANT- ALL APPROPRIATE SAFETY EQUIPMENT (GLOVES, TOOLS ETC.) MUST BE USED DURING THE INSTALLATION OF THIS PRODUCT(S). NITRO DAVE'S LLC ACCEPTS NO RESPONSIBILITY FOR INJURIES RESULTING IN THE INSTALLATION OF ANY PRODUCT(S). NITROUS OXIDE IS FOR OFF-ROAD USE ONLY.



PART NUMBER 00-11047

# INSTALLATION INSTRUCTIONS

### Step 8:

Reconnect the 12v plug and accessory wires and reinstall the center dashboard panel.





IMPORTANT- ALL APPROPRIATE SAFETY EQUIPMENT (GLOVES, TOOLS ETC.) MUST BE USED DURING THE INSTALLATION OF THIS PRODUCT(S). NITRO DAVE'S LLC ACCEPTS NO RESPONSIBILITY FOR INJURIES RESULTING IN THE INSTALLATION OF ANY PRODUCT(S). NITROUS OXIDE IS FOR OFF-ROAD USE ONLY.




PART NUMBER 00-11047

## INSTALLATION INSTRUCTIONS

## **Tips From The Pro's**

When wiring your switch panel, double check all of your wiring connections. For a clean, professional install we recommend using heat shrink of all crimped connectors. This will protect the connection, and make the connection stronger between the wire and crimp-on connector.

If you have any questions regarding the installation or operation of your Nitrous Outlet Switch Panel, please call the Nitrous Outlet Tech Support Line at (254) 848-4300 or (866) 648-7637. We are available to answer your questions or concerns Monday-Friday, 8:30am-5:30pm CST.




### Four Button Switch Panel Wiring Diagram

IMPORTANT- ALL APPROPRIATE SAFETY EQUIPMENT (GLOVES, TOOLS ETC.) MUST BE USED DURING THE INSTALLATION OF THIS PRODUCT(S). NITRO DAVE'S LLC ACCEPTS NO RESPONSIBILITY FOR INJURIES RESULTING IN THE INSTALLATION OF ANY PRODUCT(S). NITROUS OXIDE IS FOR OFF-ROAD USE ONLY.



PART NUMBER 00-11047

## INSTALLATION INSTRUCTIONS



IMPORTANT- ALL APPROPRIATE SAFETY EQUIPMENT (GLOVES, TOOLS ETC.) MUST BE USED DURING THE INSTALLATION OF THIS PRODUCT(S). NITRO DAVE'S LLC ACCEPTS NO RESPONSIBILITY FOR INJURIES RESULTING IN THE INSTALLATION OF ANY PRODUCT(S). NITROUS OXIDE IS FOR OFF-ROAD USE ONLY.