

## LED TROFFER FIXTURE INSTRUCTIONS

### CAUTION

TURN OFF THE MAIN POWER AT THE CIRCUIT BREAKER BEFORE INSTALLING THE FIXTURE, IN ORDER TO PREVENT POSSIBLE SHOCK.



### GENERAL

- All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.
- Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.


### MOUNTING INSTRUCTIONS

READ IMPORTANT SAFETY INFORMATION FIRST ON REVERSE SIDE OF THIS SHEET.

#### COMMERCIAL INSTALLATION (T-BAR CEILING)



- 1** Remove the wire connection cover on the fixture, by using a phillip screwdriver.



- 2** Remove 1/2" knockout by using a flat screwdriver (See fig.1).




- 3** Install the conduit connector (by others) on the knockout hole (See fig.2).



- 4** Make sure power is off from the circuit breaker or fuse. Feed the conduit and the building supply wires through the conduit connector.



- 5** Connect the building ground wire to the fixture ground screw (See fig. 3) connect the building supply neutral wire to the N side of the connecting block and connect the building power supply wire to the L side of the connecting block (See fig. 4), do this by pressing down on the tab of the connecting block and by inserting wire into the slot hole (See fig. 5). Make sure wires are properly inserted into the connecting block.



- 6** Place all wiring back into the panel wiring compartment and re-install wire connection cover back into place.



- 7** Once fixture has been put into place, secure fixture to the building structure using wire. On the back near the corners of the fixture, tie hanging wire from the building structure through the eye loops provided on the fixture. (See fig.6)

SAVE THESE INSTRUCTIONS.