

RECOMMENDED ZONES MAP

Recommended zones map

This unit has an automatic frost prevention mode, which disables the energy recovery function and allows the unit to work as a normal ventilation fan. (Fresh air will not come into the house during frost prevention mode.) The following map outlines the recommended use zones of the United States and Canada for ductless Energy Recovery Ventilators.



Operation Season

Zone A: Unit can perform optimally throughout the year.

Zone B: Unit can perform optimally between March through November.

Frost prevention mode may engage, December through February.

Zone C: Unit can perform optimally between April through November.

Frost prevention mode may engage, December through March.

Zone D: A ductless ERV is not recommended due to extremely cold year-round weather.

Note:

This map is based on average temperature readings over 10 years from 60 major cities in North America. Actual performance may vary depending on temperature differences and varying altitudes.