
# HOW TO RESOLVE HEATED SEAT MALFUNCTIONING-BIDET TOILET (SEAT REPLACEMENT)



#### 1. Open the cover base



① Unplug the cord




② Close the water valve clockwise




damage.

3 Unscrew the 2 screws at the back using a Philips head driver.



4 Detach the cover base by pulling it to the arrow direction as above.





(5) Make sure that the degree between the ground and the cover base is shown as in the above picture to avoid any wire






#### 2. Detach the seat harness







① Detach any connection that connects the MAIN PCB and the seat wire harness.




#### 3. Detach SEAT COVER, SEAT



① Place the bidet like the photo



3 Detach the Seat cover in the direction shown




② Unscrew the 4 screws that is connected with the damper and detach it in the direction shown in the photo.



4 Detach the Seat in the direction shown



#### 4. How to replace the SEAT




① Put the seat harness wires inside the hole and attach the seat



3 Place the unit like the photo




② Attach the SEAT COVER shown in the photo




4 Attach the damper into the hole and screw the 4 screws shown in the photo.



#### 5. Assemble the SEAT and SEAT COVER





① Attach all harness that connects the seat and the MAIN PCB in same color.






② Use the longest white harness and rotate all wires 3 times so it can get organized.



#### 6. Close the Cover Base




① Organize all the wires in the directions as above not to interfere the nozzle movement.



② Close the cover base in the arrow direction as above.



3 Push down using your palms as above to hear clicks.



④ Check whether the cover base is assembled perfectly. If you heard clicks, it's perfectly done.



⑤ Screw the 2 screws back using a Phillips head driver.

