


# ORVIN

## INSTRUCTION MANUAL

Thank you for purchasing this ORVIN watch. The following instructions are provided to help familiarize yourself with the proper operation and care of your ORVIN watch. To ensure correct use, please read and follow the instructions carefully.



### MOVEMENT

TIME MODULE VK64

### TIME SETTING

To set the time of your ORVIN watch follow these steps:

1. Pull the crown out to position 2.
2. Turn the crown clockwise to set hour and minute hands to set the time.  
Take a.m./p.m. into consideration when setting the hour and minute hands to the desired time.
3. Push the crown back to position 0.

### DATE SETTING

To set the date of your ORVIN watch follow these steps:

1. Pull the crown out to position 1.
2. Turn the crown clockwise to set the date.
3. After the date has been set, push the crown back to position 0.

Do not set the date between 9:00 p.m. and 3:00 a.m., otherwise the date may not change properly. If it is necessary to set the date during that period, first change the time to any time outside it, set the date, and then reset the correct time.

# ORVIN

## RESET

1. Pull the crown out to position 2.
2. Press button 3 for two seconds and release the button.
3. Push the crown back to position 0.


It is not necessary to set the chronograph hands after the battery is exchanged. If the chronograph hand positions are incorrect, follow below procedure, all the chronograph hands will be reset to "0" position.

## HOW TO USE CHRONOGRAPH

1. Press button 3 to start the chronograph.  
The chronograph hands will start moving.
2. Press button 3 again to stop the chronograph.  
The chronograph hands stop to indicate the elapsed time
3. Press button 4 to reset the chronograph.  
All the chronograph hands will be reset to "0" position.

The chronograph can measure up to 60 minutes and stops after a measurement of 60 minutes.

## HOW TO USE BASE MILE



This function enables users to determine average speed based on a measurement of the amount of time it takes to travel a certain distance (1 mile). It can also be used to determine the rate of production per unit of time (per hour). (measuring range: maximum 60 seconds)

- 1) Start the chronograph by pressing the Button A.
- 2) Press button A again once 1 mile has been passed.
- 3) Read the numeral on the Base Mile scale at which the stopwatch second is pointing.  
(For example, if the hand is pointing at 80 on the Base Mile scale, that means an average speed of 80 miles/hr.)

\* The measurement time of Base Mile is 1 minute or less. Please note that if the measurement time exceeds 1 minute, the average speed per hour cannot be read.

# ORVIN

## PRECAUTIONS AND PREVENTIVE MEASURES

- **TEMPERATURE & SHOCKS**  
Avoid thermal or other shocks as it may harm your watch. Do not expose your watch to sudden temperature changes (exposure to sunlight followed by immersion in cold water) or extreme temperatures [over 60°C (140°F) or below 0°C (32°F)].  
While your watch is water-resistant, it is not recommended to shower or wash dishes while wearing it as it can result in a sudden change of temperature.
- **MAGNETIC FIELDS**  
Do not expose your watch to intense magnetic fields such as loudspeakers, portable telephones, computers or refrigerators, and other electromagnetic appliances.
- **HARMFUL PRODUCTS**  
Avoid direct contact with solvents, detergents, and perfumes, cosmetic products etc., since they may damage the bracelet, the case and/or the gaskets.
- **CARE**  
Clean the case and bracelet regularly using a soft cloth to prevent any corrosion caused by perspiration. To clean all water-resistant watches use a toothbrush and soapy water, and then dried with a soft cloth. After being worn in the sea, the watch must be rinsed with warm fresh water and then dried thoroughly.

## WATER RESISTANCE

Water resistance of watches is rated based on laboratory pressure tests comparable to a swimmer or diver sitting still at that pressure level. However, many water-based activities involve movements and other environmental changes. These exceptions to how the watch was rated may challenge or defeat the water protection features of a water-resistant watch.

The water resistance of a watch cannot permanently be guaranteed. It may be affected by aging of gaskets or by accidental shock to the crown. The water resistance level of your ORVIN watch is indicated on its caseback:

1. [3atm / 30m / 100ft]  
Watches water resistant to 30 meters /100 feet.
2. [5atm / 50m / 165ft]  
Watches water resistant to 50 meters /165 feet.
3. [10atm / 100m / 330ft]  
Watches water resistant to 100 meters /330 feet.
4. [20atm / 200m / 660ft] [30atm / 300m / 1000ft]  
Watches water resistant from 200 to 300 meters /660 feet. to 1000 feet.

# ORVIN

According to the water resistance 1, 2, 3, 4, listed above, watches are protected against:

1. 30 meters /100 feet ---- Water splashes / Rain
2. 50 meters /165 feet ---- Shower & Bath with no direct stream / Shallow water activities
3. 100 meters /330 feet ---- Water sports / Snorkeling / Swimming
4. 200 to 300 meters /660 feet. to 1000 feet. ---- Scuba diving

Also, never activate the time-setting crown and/or the pushers while the watch is underwater and make sure the crown is pushed/screwed down tightly after every operation.

This manufacturer's warranty does not cover:

1. Wear and tear and aging (e.g. scratched crystal; alteration of the color and/or material of non-metallic straps and chains, such as leather, textile, rubber; peeling of the plating).
2. Any damage on any part of the watch resulting from abnormal/abusive use, lack of care, negligence, accidents (knocks, dents, crushing, broken crystal, etc.).
3. Incorrect use of the watch and non-observance of the instructions provided by ORVIN.
4. The ORVIN watch handled by reputable jeweler (e.g. for battery replacement, services or repairs) or which has been altered in its original condition beyond ORVIN control.

All applicable implied warranties, including the implied warranty of merchantability and fitness for a particular purpose given to you by law are hereby limited to the duration of this warranty. Under no circumstances will ORVIN be liable for any indirect or consequential damages of any kind.