


Ultrasonic Top-Fill Cool Mist Humidifier
Model: AroMist-TF4



This user manual provides safety and operating instructions.
Please read this user manual thoroughly before using the product.
This user manual will help get your humidifier going in just a few quick minutes.

TABLE OF CONTENTS

Important Safety Instructions	4
Introduction	5
Getting to Know Your Humidifier	6
General Tips	7
Operation	9
Using Essential Oils with AroMist-TF4	12
Cleaning & Care	12
Storage	14
Disposal	14
Troubleshooting	15
Warranty Information	16
Defective Products & Returns	18
Customer Support- Australia	18

PACKAGE CONTENTS

1 x AroMist-TF4 Humidifier
1 x Remote Control
5 x Aroma Pad
1 x User Manual
1 x Warranty Card

PRODUCT SPECIFICATIONS

Power Supply	220 - 240 V , 50 Hz
Rated Power	25 W
Standby Power	< 1 W
Water Tank Capacity	4.0 L
Mist Volume	Low: 100 ml/H Medium: 200 ml/H High: 300 ml/H
Noise Level	≤ 25dB
Coverage Area	10-30 m ²
Running Time	12-40 hours*
Night Light	Optional LED Light
Net Weight	1.8 kg
Product Dimensions	19 × 19 × 32 cm
Essential Oil Diffuser	Essential Oil Tray
Cord Length	1.5 m

* Running time may vary depending on mist level and amount of water in the tank.

THANK YOU FOR CHOOSING TO BUY AN AROVEC HUMIDIFIER

We are here to help you with any questions.
Customer Support- AUSTRALIA

- 🌐 www.rovec.com.au
- ✉ support@rovec.com.au
- 📱 @roveclifestyle

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions before use to prevent the risk of injury, fire, electric shock or damage. Use your humidifier safely by following the instructions in this user manual.

- ALWAYS turn off and unplug the humidifier before filling or cleaning the water tank.
- DO NOT use the humidifier if it has been dropped, damaged, left outside, dropped in water, is defective or not working properly.
- DO NOT use the humidifier if the cord or plug looks damaged.
- DO NOT use the humidifier near gas appliances, fire places, stoves, candles, or heating devices.
- DO NOT use the humidifier in an area with insect repellents, burning incense, toxic fumes, flammable dust or oxygen tanks. Always leave at least 1.5 m of clear space from any oxygen being administered.
- PLACE the humidifier in a clear space that allows the mist to flow freely, away from appliances that are sensitive to water.
- DO NOT touch any part of the humidifier or plug with wet hands.
- DO NOT run the power cord under furniture, other appliances, carpet, cover with rugs, runners or floor coverings.
- ALWAYS tuck away the power cord to prevent tripping accidents.
- DO NOT use the power plug on wet or damp surfaces.
- DO NOT put the humidifier in water or liquids.
- DO NOT use the humidifier outdoor.
- DO NOT use for commercial purposes. This appliance is for household use only.
- DO NOT put fingers or any objects into the mist outlet.
- DO NOT use a defective humidifier or attempt to repair/adjust any electrical or mechanical functions, this may cause danger and void the warranty.
- DO NOT let children or people with reduced physical or mental capabilities to use or clean the humidifier.
- DO NOT let children play with this appliance or packaging including plastic bag. Children must be supervised around the humidifier to help keep them safe.
- DO NOT sit on the humidifier or put any objects on top of the unit.
- DO NOT block/obscure the air inlet and mist outlet.
- DO NOT fit the humidifier with a different power supply unit.
- It is recommended to NOT use the appliance with an extension cord to avoid electrical shock or spark.
- TURN OFF the humidifier when it is not being used. Hold the plug and remove it from the electrical source. Drain the water and clean the water tank.

KEEP THESE INSTRUCTIONS IN A SAFE PLACE.

INTRODUCTION

The AroMist-TF4 ultrasonic cool mist humidifier generates a relaxing and scented mist that moisturizes the air with calming aromatherapy.

Product Features:

Humidifier: Cool mist moisturizes and refreshes the air in your home or office. This Arovec humidifier uses advanced ultrasonic technology to turn water into a therapeutic cool mist.

Aromatherapy: Enjoy the ultimate aromatherapy experience using your favourite essential oil (oil not included in the package). This is an additional feature of this humidifier and not required to run the unit.

Top-Fill Design: Large water tank opening at top of the humidifier is a unique feature of the AroMist-TF4 that allows easy refilling and cleaning of the water tank.

360° Rotatable Nozzle: The nozzle on top of humidifier is adjustable all around, so you can easily point it in the direction you would like the mist aimed.


Removable Water Tank: The water tank with handle can be easily removed for refilling and cleaning.

Auto Shut-OFF: The humidifier automatically turns off when running out of water to avoid damage to the unit.

Sleep Mode Function: Sleep mode turns off all display indicator & light and the unit runs quietly without disturbing your sleep.

Remote Control: It is featured with a remote control to easily operate and control the machine conveniently.

GETTING TO KNOW YOUR HUMIDIFIER



GENERAL TIPS

- DO NOT place the humidifier on carpet, towel or soft surface, which will block the air inlet and may damage the humidifier. For more efficiency, place the humidifier on a flat surface, 60 cm away from the floor and 30 cm away from the wall.
- DO NOT place the humidifier on wooden furniture as it may damage by water.
- DO NOT put the humidifier on an unstable surface e.g. bed or couch. [Figure 1.1]




Figure 1.1

- DO NOT add water into the humidifier through the mist outlet or base. [Figure 1.2]




Figure 1.2

- DO NOT direct the mist nozzle against the wall or window. [Figure 1.3]



Figure 1.3

- The most comfortable relative humidity is between 40% - 60%. Please adjust the mist level as needed. [Figure 1.4]




Figure 1.4

- DO NOT add essential oil directly into the water tank or base. Only add recommended drops of essential oil into the oil tray. [Figure 1.5]




Figure 1.5

- Using tap water with a high mineral content (hard water) in any humidifier can cause a fine white dust to be emitted. To avoid this, use distilled, demineralised or cold boiled water. Room temperature water is recommended, do not fill with hot water.
- DO NOT move the humidifier while it is still running and when water tank is full to prevent water spillage. [Figure 1.6]



Figure 1.6

OPERATION

Follow the bellow steps to easily and effectively use the AroMist-TF4 humidifier

Add Water:

- Remove the top cover from the humidifier. Fill the water tank with cold or room temperature water. DO NOT fill above the "MAX" level. [Figure 2.1]




Figure 2.1

- Optionally, add 5 to 10 drops of essential oil into the oil tray. For best results, it is recommended to use pure essential oil. [Figure 2.2]




Figure 2.2

Setting Up The Remote Control:

Pull the plastic film from the battery compartment. The battery is now active, and you can use the remote control. [Figure 2.3]




Figure 2.3

Changing The Battery:

1. Push the release button inwards and pull the battery casing out. Remove the old battery.
2. Insert 1 x CR2025 3V battery into the battery casing ensuring you follow the polarity (+ and -) marked on the casing. [Figure 2.4]






Figure 2.4

3. Slide the battery casing back into the remote control until you hear it click firmly into place.

Control Panel & Display:

Plug the humidifier into an electrical outlet.



Power Button:

- Tap (⏻) once to turn the humidifier ON or OFF.



Mist Level Button:

- There are 3 mist level options: 1 (low), 2 (medium), 3 (high).
- Each tap will toggle to the next mist level option.



Sleep-mode & Night Light Button:

Sleep Mode Function:

- In sleep-mode, the humidifier runs quietly on the lowest mist level and all indicators including night light turn OFF.
- Tap once (🌙) to enter sleep mode. The display blinks for 5 seconds, then all display indicator and night light turn OFF.
- To end the sleep mode, tap any button.

Night Light Function:

- Tap and hold the (🌙) for 3-5 seconds to turn the night light ON or OFF.



Timer Button:

- You can set a timer for up to 12 hours.
- Tap (🕒) repeatedly to select a timer.
- The timer display will automatically count down as time passes.
- The humidifier will automatically turn off once the timer has finished counting down.
- To cancel the timer, tap (🕒) repeatedly until the timer display disappears.

Waterless Auto Shut-off

- When the water tank runs out of water, the humidifier will stop misting. It is designed for safety to prevent the humidifier from possibly overheating and damaging the atomiser.

USING ESSENTIAL OILS WITH AroMist-TF4

Enjoy the ultimate aromatherapy experience using your favourite essential oil (oil not included in the package). This is an additional feature of this humidifier and not required to run the unit.

Please follow below recommendations for proper use of essential oils to avoid product malfunction/damage or any harm to the users.

- Use 100% natural essential oil.
- Add 5 to 10 drops of essential oil into the oil tray. **DO NOT** exceed the suggested amount of oil.
- **DO NOT** add essential oil directly into the water tank or base. Only add recommended drops of essential oil into the oil tray.
- **DO NOT** spill essential oil on your skin. If you do, wash it off with water immediately.
- **DO NOT** swallow the essential oil or contact with eyes. If you do, wash your eyes and seek medical help immediately.
- Pregnant women, elderly people, young children or people with chronic diseases may be more sensitive to a particular fragrance. Stop using of any essential oil that makes you feel unwell.
- Keep the essential oil tightly closed and store in a dark, cool place, out of the reach of children and pets.
- Carefully observe the expiration date of the essential oil. The standard expiration date is one year from first opening for most oils. However, citrus oils have a 6-month expiration date.

Arovec's 100% Pure Essential Oils (not included in AroMist-TF4 package) are the best way to take advantage of the AroMist-TF4 aromatherapy benefits.

Visit arovec.com.au for more details and orders.

CLEANING & CARE

Arovec recommends basic & deep cleaning regularly and daily water changes of AroMist-TF4 to prevent bacterial growth.

DO NOT use any harsh cleaning agents e.g., bleach or alcohol to clean any part of the humidifier.

Basic Cleaning:

Arovec recommends basic cleaning the humidifier every 3 days.

1. Turn OFF and unplug the humidifier from the power source.
2. Remove and wash the top cover.
3. Remove the water tank. Drain water from the tank and base. Pour water from the base carefully as the instructed corner of base face down. Flooding the electrical components can damage the device. Do not let water inside the air inlet/outlet or near the indicators. [Figure 3.1]
4. Rinse the water tank and base with cool and clean water.
5. Wipe down and dry all parts of humidifier with a soft cloth.

Deep Cleaning

Arovec recommends deep cleaning the humidifier every 2 weeks and before/after storing it for long periods of time. You should also deep clean if there is any mould or scale build-up inside the water tank or base. To properly clean your humidifier, Arovec recommends to remove scale/mould, disinfect the humidifier and clean the dustproof sponge.

1. Turn OFF and unplug the humidifier from the power source.
2. Remove and wash the top cover.
3. Remove the water tank. Drain water from the tank and base. Pour water from the base carefully as the instructed corner of base face down. Flooding the electrical components can damage the device. Do not let water inside the air inlet/outlet or near the indicators. [Figure 3.1]




Figure 3.1

4. Fill the water tank about half way. Add in 1 teaspoon of undiluted distilled white vinegar into the water tank and allow to soak.
5. Place the water tank back onto the base. Let the vinegar and water solution enter the base. This will help to loosen mineral scale/build-up on the atomiser, water floater and base of the water tank. Leave it for 20-30 minutes. [Figure 3.2]




Figure 3.2

6. Remove the water tank from the base. Drain the solution from the water tank and base. Wipe water tank, atomiser, floater and base with a soft cloth to remove loosened scale.
7. Flip the water tank over and clean the mist tube with a soft brush.
8. Rinse the water tank and base thoroughly to remove any sediment, dirt and smell of vinegar.
9. Wipe down and dry all parts of humidifier with a soft cloth
10. For better performance, wash and clean the dustproof sponge (at the bottom of base) and oil sponge (in oil tray) with water at least once a month.

STORAGE



If not using the AroMist-TF4 for an extended period of time, the following points must be considered for safe storage:

1. Ensure that the AroMist-TF4 is turned off and unplugged.
2. Carefully clean the humidifier.
3. Make sure the humidifier is entirely dried after cleaning.
4. Wrap the humidifier in plastic packaging and store it in a dry place to avoid moisture damage.

Note: Store the AroMist-TF4 in an upright position. Do not store anything on the top of the humidifier.

DISPOSAL



To prevent possible harm to the environment or human health from uncontrolled disposal, separate the unneeded humidifier and its related accessories from other types of wastes.

Ask your local council where to dispose of your humidifier and its related accessories. You should not throw your humidifier and its related accessories away with the daily normal household waste.

TROUBLESHOOTING

Here are some tips to try if your humidifier isn't working properly.

Problem !	Possible Solution ✓
AroMist-TF4 won't turn on or buttons not working	Plug into a powered electrical outlet.
	Try plugging the AroMist-TF4 into a different outlet.
	AroMist-TF4 or the cord might be damaged.
	Make sure there is enough water in the water tank.
	Clean the particles settlement from the water tank and base.
Air blows but water mist is not produced	Water floater stuck. Adjust the water floater to a horizontal position and make sure it can rise up with water.
	Try plugging the AroMist-TF4 into a different outlet.
	Check if there is enough water in the water tank.
	Make sure the water tank is correctly attached to the base.
	The base might be overfilled. Remove the water tank, drain the base water and replace the water tank on the empty base.
Reduced mist level	Mineral build-up on atomiser. Clean scale from atomiser.
	The water in the unit is too cold, replace with room temperature water.
	Do not fill with hot water, room temperature water is recommended.
	Mist level is set too low for the room size. Adjust the mist level.
Water leakage	Close doors or windows to reduce air ventilation.
	Water tank maybe damaged.
	Water tank is not placed properly on the base.
The mist has bad smell	Base water-level controller is stuck. Adjust the water-level controller to a horizontal position and make sure it can rise up with water.
	Clean the water tank and base thoroughly and fill the water tank with fresh water.
	Wash and clean the oil tray and oil sponge for every oil change. unpleasant odour may produce if mixed with another essential oil.
	Leave the empty water tank and base open in a cold place for 10 hours make sure the top cover is not attached to the water tank.
White dust is forming on nearby furniture	Hard water may deposit a certain kind of dust with any humidifier. Dust in the air also settles because of added humidity in the room.
	Use distilled, demineralised or cold boiled water if this becomes a nuisance.
Mist height is low. Condensation forms around humidifier on desk, floor, windows or walls	Mist level is set too high for the room size. If the room is too humid, open door and windows and adjust to low mist level.
	Low indoor temperature causes liquefaction.
	Air inlet is blocked. Ensure the unit is placed on a hard, flat surface and air inlet is open.
	Ensure the humidifier is placed 60 cm away from the floor and 30 cm away from sides.
AroMist-TF4 has stopped working	Check if there is enough water in the water tank.
	Water floater stuck. Adjust the water floater to a horizontal position and make sure it can rise up with water.
AroMist-TF4 is getting too hot	AroMist-TF4 is continuously working for too long time. Turn off for 15 minutes.
	AroMist-TF4 must be placed on a flat level and hard surface.
Increased noise level	While the humidifier is working it may generate water noise as water is going down to the base. This is normal.
	A foreign object might be stuck inside the AroMist-TF4.

If your problem isn't listed in the above table, please contact customer support at support@arovec.com.au for assistance.

WARRANTY INFORMATION

Arovec humidifiers are designed and manufactured to the highest quality standards. Your humidifier is covered for 2 years warranty, which includes 1-year standard warranty and 1-additional year upon registration, from the date of original purchase.

Product name	Ultrasonic Top-Fill Cool Mist Humidifier
Model	AroMist-TF4
Standard warranty period	1 Year
Additional warranty	Extend your warranty for 1- additional year. Simply register on to arovec.com.au/warranty within the first 14 days of original purchase.
Record your order details here. This will help if you have any warranty questions in the future.	
Date of original purchase	
Order number	

Terms And Conditions:

In addition to your rights under the Arovec warranty, you are also covered by guarantees under Australian Consumer Law. The Arovec warranty is only available in Australia.

In Australia our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

What is Covered:

- The repair or replacement of your Arovec humidifier (at Arovec’s discretion) if the product is found to be defective due to faulty manufacture. Arovec reserves the right to determine if the fault requires a replacement or repair.
- Packaging and instructions of a faulty humidifier may also be replaced if damaged.
- This warranty is valid for using your humidifier within Australia.
- This warranty is valid for personal use only.
- Warranties are limited to the 2 years (1-year standard and 1-additional year upon registration) from the date of original purchase.

What is Not Covered:

- Using your humidifier for commercial purposes, or anything other than normal domestic use.
- Using your humidifier outside of Australia.
- Accidental damage or faults caused by neglect, misuse, vandalism and abuse.
- Damage or faults caused by not following the instructions in this user manual.
- Unsupervised use by children under the age of 18.
- Repairs or alterations carried out by parties other than Arovec or an authorised agent.
- All other conditions that are not covered by Arovec warranty as listed in the “What is Covered” section.

This warranty is not transferrable:

Arovec is not responsible or liable for any damages, losses or inconveniences caused by product failure or accidental damage or faults caused by not following the instructions or safety warnings contained in this user manual.

Please email at support@arovec.com.au with any further inquiries about Arovec warranty or to ask about making a warranty claim. You must contact us within your warranty period for your claim to be eligible.

DEFECTIVE PRODUCTS & RETURNS

Once your product proved as a defective within the specified warranty period, stop using it and contact customer support at support@arovec.com.au with your order number.

CUSTOMER SUPPORT - AUSTRALIA

Feel free to contact our helpful customer support team with any questions or inquiries regarding your product.

Your satisfaction is our priority.

Customer support:

Ausbrilliant Brands

PO Box2, Ermington NSW 1700, Australia

www.arovec.com.au

support@arovec.com.au

Please provide your order number when you contact customer support.



www.arovec.com.au