


PRIME

Noosa TT Aero Handlebar Assembly Manual



Part #	Description	Quantity	Torque Setting
1	Main Handlebar Body	1	-
2	TT Bar Extensions	2	-
3	TT Extensions Clamps	2	-
4	Attachment End Clamps	2	-
5	Riser Leveling spacers	2	-
6	Risers - 15mm	2	-
7	Pad Cradle	2	-
8	Clamping Bolts	4	6-7NM
9	Clamping Bolt Washers	4	-
10	Pad	2	-
11	Extension Top Barend	2	-
12	Extension Lower Barend - Cable Exit	2	-

Installation instructions

1. install main handlebar body (1) to the stem and tighten to stem manufacturers recommend torque setting.
2. Place the clamping bolts (8) through the clamping bolt washers (9) pad cradle (7), TT extension clamps (3), risers (6) and riser leveling spacers (5) as specified in the image below. Then position on the main handlebar body. Place the attachment end clamps on the underside of the handlebar and hand tighten the bolts.
3. Insert the extensions and position accordingly to the riders preference.
4. Tighten the clamping bolts (8) to 6-7nm. Ensure the bars are angled to the riders preference.

