



Lift lid up using the handle in the center of the lid. When the lid is fully open you will feel it lock into place.




To lower the lid, lift straight up on the center handle then lower to the closed position.



After the lid is locked in the open position remove the grill grate and set aside.



After the grill grate is removed you will be able to get to your wheels, small parts kit and thermometer.



To remove the charcoal grate lift up using the side handles. Lift front side up towards you while you're lifting it out of the fire box.



To remove the ash pan you will need to lift using one of the front handles in one hand and one of the back handle in the other hand and lift straight up. Then



... You will also need to tip the front side of the ash pan up towards you when you near the top of the smoke box.



Lift front table up and lock into position.

See our New Owner Demo Video at WWW.TheGood-One.com



Installing the wheels will require two people.

Cut the metal banding loose that is holding the Marshall to the skid.

Have someone tilt the Marshall sideways just enough for you to get the wheel on.

Place the flat washer on 1st then the tire/wheel and then put the cotter key through the hole in the axle.

Bend the key using a pair of needle nose pliers.

Let the cooker back down and repeat the process on the other side.

See our New Owner Demo Video at WWW.TheGood-One.com