



# The Canada POPCORN Company









Pop Goes The Kernel













### HARDWARE







***Screwdriver (1pc) & Wrench (2pc) also included.***

			
<p>Wheel Bolt M8x1 (O) - 2pc</p>	<p>Nyloc Nut M8 (P) - 2pc</p>	<p>Nut M8 (Q) - 12pc</p>	<p>Washer (R) - 18pc</p>
			
<p>Bolt M8x60 (S) - 4pc</p>	<p>Bolt M8x35 (T) - 2pc</p>	<p>Bolt M8x16 (U) - 8pc</p>	<p>Screw M4x8 (V) - 8pc</p>

# Parts List

*We recommend two people for cart assembly.*


			
<p>Rubber Feet (A) - 2pc</p>	<p>Support Legs (B) - 2pc</p>	<p>Support Stand (C) - 2pc</p>	<p>Wheels (D) - 2pc</p>
			
<p>Horizontal Supports Base (E) - 2pc</p>	<p>Horizontal Supports with Screws (F) - 2pc</p>	<p>Cabinet Base (G) - 1pc</p>	<p>Cabinet Front with Door (H) - 1pc</p>

			
<p>Cabinet Back (I) - 1pc</p>	<p>Working Platform (J) - 1pc</p>	<p>Working Platform Brackets (Large) (K) - 2pc</p>	<p>Push Handle (L) - 1pc</p>
			
<p>Handrail Brackets (Small) (M) - 2pc</p>	<p>Handrail (N) - 1pc</p>		

# Popcorn Cart Assembly


## **STEP 1:**

Screw one of the **RUBBER FEET (A)** into the bottom of each **SUPPORT LEG (B)**. Tighten both rubber feet.



## **STEP 2:**

Insert one **WHEEL BOLT (O)** into the bottom holes located on each side of the **SUPPORT STAND (C)**. *NOTE: Insert bolt from the inside out.* Secure wheel bolts with one **NUT (Q)** on each side. Tighten with wrench.



## **STEP 3:**


Hang one **WHEEL (D)** onto one **WHEEL BOLT (O)** and secure with one **NYLOC NUT (P)**. Tighten with wrench. Repeat step for second wheel. *Note: Do not overtighten. Make sure both wheels spin freely.*

## **STEP 4:**

Attach both **HORIZONTAL SUPPORTS - BASE (E)** to the same **SUPPORT STAND (C)** using two **BOLTS (T)** each with one **WASHER (R)**. Tighten with wrench.

## **STEP 5:**

Insert two **BOLTS (U)**, each with one **WASHER (R)**, into each **SUPPORT LEG (B)**. Attach **SUPPORT LEG (B)** to the **SUPPORT STAND (C)** on the opposite side of the wheels. Tighten with wrench.




# Popcorn Cart Assembly (cont.)

## **STEP 6:**

Insert both **HORIZONTAL SUPPORTS - WITH SCREWS (F)** into the grooves at the ends of each **SUPPORT STAND (C)**, as shown.


## **STEP 7:**

Insert the **CABINET BASE (G)**. *Note: Place the lipped side facing down.* Line the cabinet base up between the **SUPPORT STANDS (C)**.



## **STEP 8:**

Confirm the **CABINET BASE (G)** is locked in place. Secure the **SUPPORT STANDS (C)** using the **SCREWS (V)**, as shown. Tighten screws with screwdriver.




# Popcorn Cart Assembly (cont.)

## **STEP 9:**

*Note: Before assembling the front and back panels, determine which side you want the cabinet door facing.*

Insert the **CABINET FRONT (H)** and **CABINET BACK (I)**. Secure both panels to the **SUPPORT STANDS (C)** with **SCREWS (V)**, as shown. Tighten screws with screwdriver.





## **STEP 10:**

Remove the pre-assembled screws from the **PUSH HANDLE (L)**. Attach one of the **WORKING PLATFORM BRACKETS (K)** to one end of the handle.

Insert the **WORKING PLATFORM (J)** to the same bracket using the pre-installed posts. Insert the screw and tighten.

Repeat steps above to attach the remaining bracket on the other side.




# Popcorn Cart Assembly (cont.)

## **STEP 11:**


Remove the pre-assembled screws from the **HANDRAIL (N)**. Attach one of the **HANDRAIL BRACKETS (M)** to one end of the handle. Insert the screw and tighten.

Repeat step above to attach the remaining bracket on the other side.



## **STEP 12:**

Using four **BOLTS (U)**, **WASHERS (R)** and **NUTS (Q)**, install the assembled **WORKING PLATFORM** on the right side of the cart (same side as wheels).



## **STEP 13:**

Using four **BOLTS (U)**, **WASHERS (R)** and **NUTS (Q)**, Install the assembled **HANDRAIL** on the left side of the cart (opposite the wheels).

