











|                 |   |   |   |  |  |  |
|-----------------|---|---|---|--|--|--|
| <b>CONTENTS</b> | <b>BODY &amp; LID</b>   | <b>POST MOUNT</b>   | <b>RAIN PEAKS X 3</b>   | <b>PORTS X 3</b>   | <b>GASKETS X 3</b>   | <b>12mm Pan Head M5 Screws</b>  X 6 |
|                 |  |  |  |                         |  | <b>12mm M5 Thumb Screws</b>  X 2    |
|                 |   |   |   | <b>PORT GUARDS X 3</b>  |  | <b>M5 Wing Nuts</b>  X 3            |
|                 |   |   |   |  |  | <b>60mm Pan Head M5 Screws</b>  X 3 |
|                 |   |   |   |  |  |  |

① Fit the feeder port gaskets to the port. These have one side that is self adhesive. The adhesive is optional but if you would like to use it simply peel off the backing from the gasket.



② Insert the 60mm pan head screw from the inside out and then place the port with gasket onto the screw and into the hole. Then attach the port guard and wing nut.



③ Fully tighten the wing nut until the port and guard are a nice solid fit. Then repeat the process for the remaining ports.



④ Using the 12mm pan head screws attach the rain peaks to the body. It is optional to fit the rain peaks, if not fitted please ensure the pan head screws are screwed fully into the rivet nuts.



⑤ The post mount has 4 screw holes to fix to a post or wall. Please use fixings of your choice for this. We recommend placing the feeder at a height so you can refill it without taking off the mount.

Secure the lid and post mount base to the feeder with the two thumb screws provided.



Visit our site

