

4', 8' - 3 CCT & WATTAGE SELECTABLE LINEAR FIXTURE LR25195, LR25197

WARNING

- · To reduce the risk of death, personal injury or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards read all warnings and instructions included with and on the fixture and all fixture labels.
- · Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- · Commercial installation, service and maintenance of luminaires should be performed by a qualififed licensed electrician.
- · For the installation: if you are unsure about the installation or maintenance of the luminaires, consult a qualified licensed electrician and check your local electrical code.
- · To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- · Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.

WARNING

- \cdot Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.
- · Turn off the power when you perform any maintenance.
- \cdot Verify that supply voltage is correct by comparing it with the luminaire label information.
- \cdot All wiring connections should be capped with UL approved wire connectors.

CAUTION

- · Avoid direct eye exposure to the light source while it is on.
- · Account for small parts and destroy packing material, as these may be hazardous to children.
- \cdot Risk of burn. Disconnect power and allow fixture to cool before changing bulb or handling fixture.


 $\textbf{NOTICE:} \ \textbf{Green ground screw provided in proper location.} \ \textbf{Do not relocate}.$


NOTICE: Minimum 90° supply conductors.

NOTICE: Specifications and dimensions subject to change without notice.

NOTICE: Suitable for wet location.


GENERAL WIRING DIAGRAM








B. SURFACE MOUNTING



B. SURFACE MOUNTING

- STEP 1: Secure the provided brackets onto the ceiling by using the provided accessories and screws.
- STEP 2: Screw the covers at the outlet of the back of the housing. (FIGURE B)
- STEP 3: Wire to main power through the junction box (FIGURE C)
- STEP 4: Clip the brackets to the slots of the fixture (FIGURE D)



User may adjust the color temperature by using the DIP switch button integrated into the driver. The DIP switch is accommodated with 3 options (left, middle and right), corresponding to 3 color temperatures.

FACTORY SETTINGS:

LR25185: 38W - 4000K

LR25187: 75W - 4000K

- 1. DIP switch is located onto the LED Module holder plate (FIG. E)
- $2. \, {\sf Select \, color \, temperature \, by \, sliding \, switch \, left \, or \, right \, respectively \, to \, the \, desired \, value. \, ({\sf FIG. \, E})}$

732-882-1500 ♦ luxrite.com

2