

# LED DOUBLE RING DESIGNER WALL SCONCE - 3 CCT SELECTABLE LR40315, LR40317

#### **WARNING**

RISK OF PERSONAL INJURY - PLEASE READ THESE INSTRUCTIONS CAREFULLY. FOLLOW ALL INSTALLATION INSTRUCTIONS AND OBSERVE ALL WARNINGS.

MAKE SURE THE "SUPPLY" VOLTAGE CORRESPONDS TO THE "RATED" PRODUCT VOLTAGE 120V 60Hz

KEEP THESE INSTRUCTIONS. NOTE: IF YOU'RE AN INSTALLER, PLEASE GIVE THESE INSTRUCTIONS TO THE PROPERTY OWNER FOR FUTURE REFERENCE. RISK OF PERSONAL INJURY - ALWAYS WEAR THE NECESSARY SAFETY EQUIMPMENT TO PREVENT INJURIES WHEN OPENING, HANDLING, INSTALLING AND MAINTAINING THIS PRODUCT.

RISK OF ELECTRIC SHOCK - THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PROFESSIONAL FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT. THE PROFESSIONAL SHOULD ALSO BE AWARE OF, AND UNDERSTAND THE HAZARDS INVOLVED WITH THE INSTALLATION OF THIS PRODUCT.

RISK OF FIRE - ALWAYS CONSULT WITH A QUALIFIED ELECTRICIAN TO ENSURE THE CORRECT BRANCH CIRCUIT CONDUCTOR IS UTILIZED. THE MINIMUM CONDUCTOR RATING REQUIREMENT IS 90°C (194°F) IN ORDER TO BE CODE COMPLIANT.

#### IMPORTANT SAFETY INFORMATION:

PLEASE READ ALL OF THE INSTRUCTIONS BELOW BEFORE INSTALLATION.

- MAKE SURE THE "SUPPLY" VOLTAGE CORRESPONDS TO THE "RATED" PRODUCT VOLTAGE 120V 60Hz
- THE PRODUCT MUST BE INSTALLED BY A QUALIFIED CERTIFIED ELECTRICIAN IN ACCORDANCE WITH THE NATIONAL CODE AND CORRESPONDING LOCAL CODES.
- IF THE PRODUCT IS DAMAGED, DO NOT ATTEMPT INSTALLATION AND DO NOT USE.

#### **INSTRUCTIONS**

#### STEP 1. PREPARING FOR INSTALLATION

A. Disconnect electrical power at fuse or circuit breaker box before installing or servicing any part of this fixture.

B. Carefully remove fixture from carton.

C. Remove the mounting bracket (1) from the fixture (2) by removing two screws (3)

D. Install mounting bracket (1) to junction box (not included) by using two screws (4) to secure it.

## WIRING - ALL WIRING MUST TAKE PLACE INSIDE JUNCTION BOX (NOT INCLUDED)

CAUTION: MAKE SURE POWER IS OFF AT FUSE OR CIRCUIT BREAKER BOX. CHECK POWER WIRES FOR DAMAGE OR SCRAPES. IF POWER SUPPLY WIRES ARE WITHIN THREE INCHES OF THE DOB, USE WIRE SUITABLE FOR AT LEAST 90°C (194°F). NOTE: MOST DWELLINGS BUILT BEFORE 1985 HAVE SUPPLY WIRE RATED TO 60°C. CONSULT A QUALIFIFED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR BEFORE INSTALLING.

#### STEP 2. WIRING FIXTURE

A. Make all wire connections to appropriate wire. Secure with wire nuts (provided).

B. Connect the green wire from the fixture to the supply power source ground wire.

Č. For none dimming, Connect the white wire from the fixture to the white (N) wire from supply power source. Connect the black wire from the fixture to the black (L) wire from supply power source.

D. Do not mix wires. Pull on each wire lead to make sure connections are secure. Make sure no bare wires are exposed outside of wire connectors. Tuck all connectors neatly into junction box.

#### STEP 3. COLOR TEMPERATURE ADJUSTMENT (IF DESIRED)

Adjust cct switch on the back of the fixture prior to mounting accordingly to the desired color temperature.

Note: fixture is preset to 3000k from factory.

#### STEP 4. MOUNTING


A. Install fixture (2) by aligning both side holes over the mounting bracket (1) then using two screws (3) to secure it.


#### STEP 5. FOR WET APPLICATION

A. Apply a small amount of silicone (not included.) per manufacturer's recommendation around the upper perimeter of the fixture (2) where it contacts with the surface of the wall but not the bottom.

#### STEP 6. RESTORE POWER AT FUSE OR CIRCUIT BREAKER BOX.

### **BOX CONTENTS**





732-882-1500 + luxrite.com