


Dura Mobi Humbird Bone Conduction Speaker

Operation instruction:

humbird**SPEAKER**

FCC ID: 2AMKU-C801



Single Speaker Operation:

1. Long-press the power button (6) until you hear some music and the voice indicate 'Power on'.
2. Turn on your device's Bluetooth (phone / tablet) and search for 'Humbird' in the active Bluetooth devices and pair with your device. No passcode is needed.
3. On connection you will hear the voice and you are ready to place the 'HumBird Speaker' on surface of any hollow object to play. Different objects will radiate different sounds!

Duel Speakers Stereo Operation (TWS):

1. Before connecting to Bluetooth (see above), turn on one 'Humbird Speaker' by long pressing the power button (6).
2. After the power is on, double press the power button (6) quickly, you will hear a ding tone, and after that turn on the second 'Humbird Speaker' by long-pressing the power button (6) on it.
3. In a few seconds you will hear "Left channel and "Right channel" from each speaker indicating that the Stereo sound has been configured.
4. Next turn on your device's Bluetooth (phone / tablet) and search for 'HumBird Speaker' in the active Bluetooth devices and pair with your device. No passcode is needed.
5. On connection you will hear the voice and you are ready to place the 'HumBird Speaker' on surface of any hollow object to play. Different objects will radiate different sounds!

FM Function:

1. Short-press the Power button (6) to switch from Bluetooth mode to FM mode.
2. Long-press the Function button (2) to automatically scan for all available FM channels.
3. After scanning is finished, short-press the Function button (2) to switch between all scanned FM channels.

Charging:

The 'Humbird Speaker' is charged via the included USB-C cable from any compatible wall charger or USB port on your computer or car.

Notes:

1. After several uses, the sticky pad at the bottom of the 'Humbird Speaker' will collect dust and become less effective. Please clean the surface of the sticky pad with a wet cotton cloth to return back the stickiness of the pad. For more permanent fixing, double side tape can be useful also.
2. It is normal for the 'Humbird Speaker' to get hot when played at maximum volume. Lower the speaker volume to return the 'Humbird Speaker' to a cooler normal temperature.

FCC Warning :

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

