
# Hybrid Pro Modular Kit 07

Hybrid Pro Modular exhibits and counters are a perfect solution for the serious exhibitor. Exhibits feature heavy-duty aluminum extrusion frames and push-fit fabric graphics. Count on making an unforgeable impact with Hybrid Pro Modular exhibit kits, counters, and accessories.




We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

#### features and benefits:


- Silver aluminum extrusion frame
- Single-sided fabric graphics
- Pillowcase fabric graphic
- Easy step-by-step instructions
- Counter available in four thermoformed finishes, shown below
- Kit includes frame, side/top white accent, three fabric graphic panels, three pillowcase fabric graphics, one counter, one medium monitor mount and three molded cases
- Lifetime hardware warranty against manufacturer defects

#### dimensions:


Hardware	Graphic
Assembled unit: 115.25" w x 95.63" h x 79.25" d 2927mm(w) x 2429mm(h) x 2013mm(d) Approximate weight: 230 lbs / 105 kgs	Refer to related graphic template for more information. Visit: www.tradeshowplus.com
Shipping	additional information:
Packing case(s): 1 OCE 2 OCH2	Graphic material: Dye-sublimation zipper pillowcase fabric Dye-sublimation SEG push-fit fabric
Shipping dimensions: OCE: Expandable case length (I) may vary	Monitor mount holds 32 - 55" LCD's Monitor max weight: 50 lbs / 37 kgs
40" - 66"l x 18"h x 18"d 1016mm-1677mm(l) x 458mm(h) x 458mm(d)	Max counter weight: 50 lbs / 23 kgs
OCH2: 52″l x 29″h x 15″d 1321mm(l) x 737mm(h) x 381mm(d)	*monitor not included
Approximate total shipping weight: 317 lbs / 144 kgs	Tabletop Colors:         silver       black
	2 person assembly recommended:





## **R-HP-K-07**




Code	#	Description
EXT-M-MB	1	MEDIUM MONITOR BRACKET FOR MONITORS 32"-55"
R9	2	1200MM (47.24") PHFC4 EXTRUSION WITH MITRE CUT BOTH ENDS
R27	4	1200MM (47.24") PHFC4 EXTRUSION WITH MITRE CUT 1 END FOR CB9 ONE END-IB2 HOLES ONE END
R55	4	510MM (20.08") PHFC2 EXTRUSION WITH LOCKS 2 ENDS
R19	8	1155MM (45.47") PHFC2 EXTRUSION WITH IB2 HOLE ONE SIDE-WITH LOCK 1 END WITH SIDE CAM LOCKS
R15	4	1200MM (47.24") 100MM PM4S2 SQUARE EXTRUSION WITH PH2 STOP AT 600MM
GRAPHIC B	1	94 1/2" (H) X 47 1/4" (W) SINGLE SIDED DYESUB GRAPHIC W/ FCE-2 (SEG) ON PERIMETER
GRAPHIC A2	1	94 1/2" (H) X 23 5/8" (W) SINGLE SIDED DYESUB GRAPHIC W/ FCE-2 (SEG) ON PERIMETER
R12	2	1155MM (45.47") 100MM PM4R8 ROUND EXTRUSION WITH LOCKS 1 END WITH PH2 STOP AT 155MM
R13	2	600MM (23.62") PM4D CONNECTOR WITH TENSION GLIDES
IB2	6	PH INLINE CONNECTOR
CB9-S	8	50MM SQUARE PHCF2 CORNER BRACKET
GRAPHIC A1	1	94 1/2" (H) X 23 5/8" (W) SINGLE SIDED DYESUB GRAPHIC W/ FCE-2 (SEG) ON PERIMETER
CB9	4	CB9 CORNER BRACKET
CUSTOM FS	1	APPROXIMATELY 8' X 10' X 8' CUSTOM FABRIC STRUCTURE - TO PACK INTO OCE -
R14	1	300MM (11.81") PM4D CONNECTOR WITH TENSION GLIDES
SW-FOOT	2	SMARTWALL SUPPORT FOOT













BOM














<ul> <li>1. Redesign of this exhibit without approval by manufacturer may result in dangerous and urstefus structures. Manufacturer disclaims any responsibility for redesigned exhibits it does not approve in writing.</li> <li>2. Parts and components such as panels and structures as well as in metric. Below is the feet and inches as well as in metric. Below is the inches as well as in metric. Below is the structure is zing table as reference."Nominal" refers to approximate size.</li> <li>2.400mm = (94 1/2") 2.100mm = (82 5/8") 1800mm = (70 7/8") 1800mm = (35 1/2") 100mm = (35 1/2") 100mm = (35 1/2") 100mm = (117/8")</li> <li>2.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2.</li></ul>
HYBRID PRO RENTAL KIT Title: SET-UP INSTRUCTIONS











# **PACKING INSTRUCTIONS**



(1) MM-MB, (2) SW FOOT, (1) R14, (1) R12, (4) R55 HARDWARE BOX







(8) R15, (1) R12, (2) R13


(8) R19, (3) R27,(2) R9





#### (1) R27, HARDWARE ITEMS







FABRIC STRUCTURE



D	GREY FOAM FO
Ē	1/8" (PUT IN
0	
Ц	(USED AS PROT





# **Monitor Bracket Instructions**

#### **Tube Applications**



#### **Included hardware:**



**TCH-30** 

x2

#### ACC60 x2



#### TC-30MM-SILVER x2




BOLT-1 x4



#### Flange Wingnut x4

## **TUBE CONNECTION**

#### **ACC60 Clamp Connection**



**TCH Clamp Connection (Tablet Stands)** 



Locate all components needed to assemble the monitor mount with the TCH tube method. You will need (1) monitor bracket, (2) TCH clamps, (2) bolts, (2) washers, and (2) wingnuts. Determine your desired monitor location. **Step 1:** Fit the provided bolts through the TCH clamps then reassemble the clamp. **Step 2:** Lock the clamp onto the tube with the allen head screws on the clamp. **Step 3:** Align your monitor bracket so that the left and right holes slide onto the bolts behind them. Use your washers and wingnuts to lock your monitor bracket in place. **Step 4:** Reference the included manufacturer monitor mount instructions for fastening your monitor to the bracket.

Locate all components needed to assemble the

on the monitor bracket., adjust ACC60 position if necessary. **Step 5:** Lock your monitor bracket to the ACC60s by placing your washers and locking

with provided wingnuts. **Step 6:** Reference the included manufacturer monitor mount instructions for fastening your monitor to the bracket.

monitor mount with the ACC60 tube method. You will need (1) monitor bracket, (2) ACC60 clamps, (2) washers, and (2) wingnuts. **Step 1:** Apply pressure to the rear side of the leveling gauge clipped into the monitor mount to remove it. **Step 2:** Push the provided bolt through the hole in the ACC60 and place the ACC60 in the desired location. **Step 3:** Tighten the clamp to the tube using the plastic wingnut. **Step 4:** Set your monitor bracket onto the protruding bolts using the of the ACC60 using the center holes

### **TUBE CONNECTION**

#### **TC-30 Clamp Connection**



Locate all components needed to assemble the monitor mount with the TC-30 tube clamp method. You will need (1) monitor bracket, (2) TC-30-SILVER clamps, (4) BOLT-1 screws, and (4) flange wingnuts. **Step 1:** Insert the pan-head screws through the holes of your TC-30 clamps. Attach the TC-30 clamps to the tubes but do not tighten. **Step 2:** Set your monitor bracket onto the protruding pan-head screws on your clamps using the holes in the monitor bracket. **Step 3:** Apply your flange wingnuts to the front of your monitor bracket to lock it to the clamps. Lock your clamps securely into place. **Step 4:** Reference the included manufacturer monitor mount instructions for fastening your monitor to the bracket.