


WLM-2000H

Step 1: Assemble straight poles by pressing and pushing together.






Step 4: Unzip print and lay image face up. Slide print onto frame like a pillow case.









Step 5: Zip the edge of graphic beyond the center point as shown to hold the center pole in place. Zip the remaining side and bottom to meet at the corner.

Step 6: Complete.







LIGHTS:


(OPTIONAL) Position as desired and tighten knob to hold in place.


WARNING! Over tightening may cause damage to fabric image.




WLM-2000N


Step 1: Assemble straight poles by pressing and pushing together.






Step 4: Unzip print and lay image face up. Slide print onto frame like a pillow case.





Step 5: Zip the edge of graphic beyond the center point as shown to hold the center pole in place. Zip the remaining side and bottom to meet at the corner.

Step 6: Complete.





LIGHTS:


(OPTIONAL) Position as desired and tighten knob to hold in place.

WARNING! Over tightening may cause damage to fabric image.




WLM-2011B


Step 1: Assemble the two long curved and straight sections together. The frame is symmetrical and either of the curved sections can be top or bottom.




Step 5: Zip the edge of graphic beyond the center point as shown to hold the center pole in place. Zip the remaining side and bottom to meet at the corner.




Step 2: Connect all corner sections to curved and straight sections of the frame by matching shape symbols on pipes.




Step 3: Complete assembled frame shown.



Step 6: Complete.








LIGHTS:

(OPTIONAL) Position as desired and tighten knob to hold in place.

WARNING! Over tightening may cause damage to fabric image.

WLM-PANEL CONNECTION

FEET





CLAMPS

