



INSULATED Casserole Carrier

CUTTING INSTRUCTIONS:



3/4 yard

- (1) 22" Square
- (2) 3" x 7"
- (1) 22" x 3"




■ (1) 22" Square of Insulbrite



3/4 yard

- (1) 22" Square
- (2) 3" x 7"
- (1) 22" x 3"



STEP 1:

Take your 22" x 3" rectangle of Fabric A and Fabric B, and place them right sides together. Sew 1/4" from the edge of three sides, leaving one short side open. Once it is sewn, flip it right side out and press.




Repeat the same step with your 3" x 7" rectangles.




STEP 2:


Take your insulbrite and lay it flat on your table. Place your fabric A 22" square on top of it, with the right side facing up.




Take one of your sewn 3" x 7" rectangles and place it 1 1/2" from the top left edge as shown below. The same fabrics should be touching (so the opposite fabrics are face up). Line up the raw edge of the 3" x 7" with the top of the 22" square. Use wonderclips or pins to keep it in place.



Place the other edge of the 3" x 7" rectangle 1 1/2" from the left top left corner, creating a loop. Don't fold over your fabric. The same side of the 3" x 7" should still be facing up. Repeat for the opposite corner.




With your loops securely pinned, lay your Fabric A 22" Square right side down, sandwiching the loops inbetween fabric A and B. Sew 1/4" away from the entire edge, leaving a 5" gap.




Flip right side out and press.

Topstitch all the way around, carefully moving the loops out of the way, to close the gap.



STEP 3:

Lay your strap diagonally across your carrier as shown below. Place one edge of the strap 2" away from the corner and sew down a topstitch 1/4" from the edge. Sew the other corner 2" from the edge as well. The strap is shorter than the carrier, so it should fold up a little. Tuck in the raw edge of the strap and topstitch at 1/4".



STEP 4:

Enjoy!

