




Instruction manual (translated from Japanese by Majime Life with consent from thermo mug)

Model: AL21-36


Name: All Day Water Bottle (Insulated stainless steel bottle)

Volume: 0.36 L

Designed by thermo mug in Japan. Made in China.



Maintenance



Before use:


- Wash the bottle and lid in warm water mixed with mild detergent before use. If smell persists, wash in warm water mixed with cooking vinegar.
- Make sure all silicone seals are present in the lids and caps before use, and that they are seated properly. Leaks can occur if seals are not present or fitted incorrectly.

After use:

- Always remove the inner cap and seals for washing after use. Make sure to dry thoroughly after wash and prior to use.

Warning

- Do not microwave.
- Do not wash in dishwasher or dish dryer. Parts may deform or break in high heat.
- Keep out of reach of children. Water bottle parts may present a danger leading to suffocation, burns or cuts.



- Fill to approximately 1cm of the liquid limit line. Overfilling the bottle will lead to spillage when closing the lid, or leakage during use.

Parts information

Part	Material	Higher temperature limit	Lower temperature limit
Lid, inner cap	Polypropylene	100°C	-30°C
Seal	Silicone rubber	100°C	-30°C
Main body	Stainless steel		

Insulation properties

The table indicates the temperature of water inside the bottle after 3 or 6 hours, when either water at 95°C ± 1°C or at 4°C is filled, bottle is capped and lid shut, and left at a room temperature of 20°C ± 2°C.

Time	Starting temp 95°C ± 1°C	Starting temp 4°C ± 1°C
Temp after 3 hours	Above 72°C	Below 6°C
Temp after 6 hours	Above 59°C	Below 8°C

Usage caution

- Do not use other than with drinks.
- Do not leave next to a flame. Bottle may become heated, leading to burns.
- Make sure to close the lid and inner cap tightly, otherwise there is a risk of leakage. Always use the attached silicone seals.
- Do not fill with liquid above 100°C, or liquids with very high temperatures. There will be a risk of damage or deformation, and risk of burns.
- Do not fill with dry ice, carbonated drinks or alcohol.
- Do not close the lids while the bottle is tilted. This may lead to spillage, burns and stains.
- Avoid leaving the bottle in washing liquid for extended times.
- Fill with the appropriate amount of liquid.
- Please take care when filling with a hot drink as there is a risk of burning your mouth.
- While the bottle is leak proof when sealed properly, it is best to carry your filled bottle upright in your bag to minimize the risk of spillage.
- There is a risk of cracks or damage if the bottle is dropped or exposed to a hard shock. If there is any damage due to this, stop using the bottle immediately.
- There is risk of scratching or denting if the bottle makes hard contact or dropped on a hard object or surface.
- Do not store in the freezer as there is a risk of damage.
- Consume your drink as quick as possible. If left for too long, there could be a risk of drink poisoning due to spoilage, bottle rusting, and discolouration. If there is a drink spoilage, gases could be released leading to the lid popping off due to high pressure or breaking into many pieces.
- Make sure to consume milk or dairy, or fruit drinks as quickly as possible, as these can lead to gases being released when spoilt.
- Avoid filling with liquids that contain food pieces, such as soups, teas with leaves or fruit juices with flesh.
- There is risk of scratching if hard brushes, scrubbers, or detergents with microparticles are used during washing.
- Do not fill with any organic solvents such as thinners or benzene.
- Do not use bleach or other chlorine products.
- Please follow the maintenance steps after usage.