



Stevens I.D. SYSTEMS®
800.350.3270
www.IDSystemsStorage.com



84006



84008

84006/84008 2-STUDENT TABLES

STEP-BY-STEP INSTALLATION

ATTENTION

Please unpack and assemble in an area away from children's activities. Remove all tools and excess materials from work area after assembly of unit is complete. Dispose of pallet and packaging materials in an environmentally friendly manner. If any parts are missing or damaged, please call Stevens for immediate parts replacement (1-800-350-3270). When ordering parts, give the Model Number and Color of the unit.


NOTE:

Pulls are preinstalled on the inside of fronts and must be reinstalled on the outside. However, they are shown in their final mounting position on installation drawings.


NOTE:

*84006 requires 110V single phase electrical utilities in floor access location.
84008 requires cold water, drainage, 110V single phase electrical and gas utilities in floor access location.*

- ① Position Base Cabinet in desired location.




(front view)




(back view)

- ② **FOR 84008 ONLY:** Remove Access Panel on back side of Base Cabinet to allow access for utility hookups in later steps.





- ③ Note that there are two (2) corner Levelers located behind the toe kick on the back side of the Base Cabinet and accessible through drilled Access Holes in the cabinet floor. Remove the plastic plugs from the Access Holes in order to perform the leveling adjustments in the next step.




STEP-BY-STEP INSTALLATION

- 4** Using a level, adjust the Levelers until the sidewall, front edge and cabinet floor are plumb. Insert a 4mm hex wrench through the Access Holes in the cabinet floor to make the adjustments. Once the adjustments are complete, reinstall the plastic plugs into the Access Holes.



NOTE:
Turn clockwise to lift,
counterclockwise to lower.

- 5** Securely fasten Base Cabinet to the floor structure, using Blocking to floor behind Toe Kicks and screw attachment through Toe Kick area.




IMPORTANT!


Cabinet must be securely attached to floor structure with anchoring devices of appropriate type, size and quantity in accordance with applicable codes and accepted installation practices.

- 6** To assemble each Leg:

- A. Insert the Leveler Bracket into the bottom of the Leg Tube and tap gently with rubber mallet to secure in place. Remove Leveler Nut from Leveler Bolt. Install two (2) Leveler Anchors onto Leveler Bolt, with Anchors positioned 90° to each other. Reinstall Nut to secure Anchors to Bolt.




- B. Screw Leveler Bolt all the way into Leveler Bracket. **NOTE:** Leveler Bolt will be adjusted later.




STEP-BY-STEP INSTALLATION

- 7** Attach one (1) Leg to each Apron Rail Assembly, as follows: With Apron Rail Assembly upside down, position the Leg between the Inner and Outer Apron Rails, aligning the holes in the Leg with the holes in the Apron Rails. (NOTE: Legs are interchangeable.)


Insert two (2) 1/4 - 20 x 3.93" Hex Head Bolts through the Outer Apron Rail, Leg and Inner Apron Rail. Secure in place, using 1/4 - 20 Nuts and Washers. Snug until Legs are not loose. They will be tightened further after Apron Rail Assemblies are attached to the Base Cabinet.



- 8** With additional assistance, turn the Left Apron Rail Assembly upright and move into position for attachment to the Base Cabinet. Align the predrilled holes and notch in the Apron Rail Assembly with the corresponding holes and notch in the Base Cabinet ends.



- 9** Attach Left Apron Rail Assembly to Base Cabinet, using two (2) 1/4 - 20 x 2" Bolts through the predrilled holes in the Apron Rail Assembly and Base Cabinet, securing with 1/4 - 20 Nuts and Washers. Repeat Steps 8 and 9 for the Right Apron Rail Assembly attachment.



- 10** Snug all Apron Rail Assembly attachment bolts and finish tightening the Legs. Level the Legs to match the Apron Rail Assembly top planes to that of the Base Cabinet, by turning the Leveler Bolts. Then, attach the Legs to the floor structure, using the Leveler Anchors.


(continued on next page)

STEP-BY-STEP INSTALLATION


- 11** Drill holes to properly route electrical wiring. Route wiring conduits into rear compartment of Base Cabinet via notches. Table is provided with one (1) GFI (Ground Fault Interrupter) and one (1) Duplex Outlet in the Apron Rail Assemblies. Electrical connections for the 110V single phase duplex outlets to be performed by licensed electrician in accordance with all applicable codes.

NOTE TO ELECTRICIAN:

A GFI (Ground Fault Interrupter) is provided, and both duplex outlets must be connected to provide protection in both outlets.



- 13** Place Countertop onto Table Assembly, with an approximate 1" overhang on left and right and approximate 2" overhang on front and back of Apron Rail Assemblies, centering over Apron Rail Assemblies. Clamp Top as may be necessary until Sealant is set. (84006 countertop depicted in drawing below)




CAUTION!

Countertops are quite heavy. Please use caution when handling. Do not attempt to handle without additional assistance.


- 12** The Countertop is held in place with Clear Silicone Sealant. Apply Silicone Sealant in general locations shown below on Apron Rail Assemblies and Base Cabinet.

NOTE:

Laminate top may be additionally attached with 3/4 x 8 flat head screws through the Brackets attached to the Apron Rail Assemblies and Base Cabinet.



- 14** **FOR 84008 ONLY:** If not pre-mounted, install drop-in Epoxy Sink with Clear Silicone Sealant. Install two (2) Faucets and two (2) Gas Valves in locations shown, using silicone sealant under fixtures to seal against leakages. Install two (2) Burette Sockets into pre-drilled holes.




Allow sealant to set at least overnight before proceeding with utility hookups.

STEP-BY-STEP INSTALLATION

- 15** **FOR 84008 ONLY:** Utility hookups for cold water gooseneck Faucets, Drains and Gas Valve assemblies to be performed by licensed plumber in accordance with all applicable codes.

- 16** **FOR 84008 ONLY:** Reinstall Access Panel on back side of the Base Cabinet after completion of hookups.



- 17** Base cabinet is provided with an unfinished toe kick fascia in anticipation of 4" vinyl base application by flooring contractor, matching room décor. (It is recommended to wrap vinyl base around all four (4) faces of the Base unit.)

NOTE:

If vinyl base was purchased from I.D.SYSTEMS®, it has a self-adhesive backing. After removing the protective cover strip, take care to properly position the vinyl base before applying pressure for permanent adhesion.