Lateral Plungers · with plastic spring and pin

22150.0233



Product Description

To be used for positioning and applying pressure, e.g. during painting and sandblasting.

Material

Spring

Plastic

Pin

· Thermoplastic POM, white

Assembly

Moistening the body allows for easier installation.

Installation by pressing in.

Formula for calculating the center distance for the mounting hole:

 $I_0 = z/2 + w + x$

 I_0 = center distance,

y = workpiece height,

w = workpiece length,

w = workpiece length,

x = coordinate dimension,

s = stroke,

z = stop diameter

Calculation dimension x:

y greater than or equal to l_2 - $d_2/2$, then x =

 $d_2/2 - s$


or

y smaller than l_2 - $d_2/2$, then x = $d_2/2$ - s - $[(l_2 - d_2/2 - y) * 0,123]$


Characteristic

Standard spring load = red spring

Drawing







Order information

Dimensions		Spring load	Dimensions		Stroke	Location hole	<u>J</u>	I	Art. No.
d ₁	d ₂	F max. ¹⁾ ~	I ₁ -1	l₂ ±0,5	s	D H8	max.	_	
[mm]		[N]	[mm]		[mm]	[mm]	[°C]	[g]	
Pin: Thermoplastic/standard spring load									
8	4	30	9	5,2	0,6	7,9	80	0,59	22150.0233

¹⁾ statistical average value

www.halder.com Page 1 of 2
Published on: 12.4.2019

^{*}some sizes (see chart) have a deviating pin shape

Accessories Dimensions d₁ [mm] [g] assembly tool 8 47 22150.0841



Page 2 of 2 Published on: 12.4.2019

www.halder.com