# Lateral Plungers- with plastic spring and pin 22150.0235



## **Product Description**

To be used for positioning and applying pressure, e.g. during painting and sandblasting.

#### **Material**

## Spring

Plastic


Pin


Thermoplastic POM, white

## Assembly

Moistening the body allows for easier installation. Installation by pressing in. Formula for calculating the center distance for the mounting hole:  $I_0 = z/2 + w + x$ ,  $I_0$  = center distance, y = workpiece height, w = workpiece length, x = coordinate dimension, s = stroke, z = stop diameter Calculation dimension x: y greater than or equal to  $I_2 - d_2/2$ , then x = d<sub>2</sub>/2 - s or y smaller than  $I_2 - d_2/2$ , then x =  $d_2/2 - s - [(l_2 - d_2/2 - y) * 0,123]$ Characteristic Standard spring load = red spring

Drawing





\*some sizes (see chart) have a deviating pin shape

### **Order information**

Dimensio d <sub>1</sub>	d <sub>2</sub>	Spring load F max. <sup>1)</sup>	Dimer I <sub>1</sub> -1	l <sub>2</sub> ±0,5	Stroke s	Location hole D H8	max.	Ĭ.	Art. No.		
[mm]		~ [N]	[m	im]	[mm]	[mm]	[°C]	[9]			
Pin: Thermoplastic/standard spring load											
10	5	60	9	7,3	0,8	9,9	80	0,95	22150.0235		

<sup>1)</sup> statistical average value

Accessories									
	Dimensions	<b>I</b>	Art. No.						
	d <sub>1</sub>	_							
	[mm]	[9]							
assembly tool									
	10	46	22150.0842						