# Lateral Plungers. with thread, with seal

22150.0460



## **Product Description**

To be used for positioning and applying pressure, e.g. during painting and sandblasting. Sealed against chips and dirt.

### Material

### Seal

• CR

#### **Body**

· Steel, zinc-plated by galvanization

#### Spring

• Steel, zinc-plated by galvanization

#### Pin

Steel, case-hardened, zinc-plated by galvanization

### **Assembly**

Lateral plungers are installed by screwing in by means of a mounting tool.

Formula for calculating the center distance for the mounting hole:

 $I_0 = z/2 + w + x$ 

 $I_0$  = center distance,

y = workpiece height,

w = workpiece length,

w = workpiece length,

x = coordinate dimension,

s = stroke,

z = stop diameter

Calculation dimension x:

y greater than or equal to  $l_2$  -  $d_2/2$ , then x =

 $d_2/2 - s$ 

or


y smaller than  $l_2$  -  $d_2/2$ , then x =

 $d_2/2 - s - [(I_2 - d_2/2 - y) * 0,123]$ 

#### Characteristic

Heavy spring load = spring from steel, zincplated by galvanization

### **Drawing**



## **Order information**

Dimensions					Stroke	ws		I	Art. No.	
ď <sub>1</sub>	I <sub>1</sub> -2	Spring load F max. <sup>1)</sup>	d <sub>2</sub>	l <sub>2</sub>	s		max.	-		
[mm]		[N]	[m	m]	[mm]	[mm]	[°C]	[9]		
Pin: Steel/heavy spring load										
M18 x 1,5	45	200	10	16	1,6	16	110	38	22150.0460	

<sup>1)</sup> statistical average value

Erwin Halder KG


www.halder.com Page 1 of 2


Published on: 12.4.2019


# Accessories

Dimensions d <sub>1</sub> [mm]	<b>[</b> g]	Art. No.
assembly tool		
M18 x 1,5	137	22150.0822

# **Application example**







www.halder.com Page 2 of 2
Published on: 12.4.2019