Lateral Plungers · smooth, without seal - INCH

2B150 0070



Product Description

To be used for positioning and applying pressure, e.g. during painting and sandblasting.

Material

Body

Aluminium

Spring

· Stainless steel

Pin

· Thermoplastic POM, white

Assembly

Installation by pressing in.

Formula for calculating the center distance for the mounting hole:

 $I_0 = z/2 + w + x$

 I_0 = center distance,

y = workpiece height,

w = workpiece length,

x = coordinate dimension,

s = stroke,

z = stop diameter

Calculation dimension x:

y greater than or equal to l_2 - $d_2/2$, then x =

 $d_2/2 - s$

or

y smaller than l_2 - $d_2/2$, then x =

 $d_2/2 - s - [(l_2 - d_2/2 - y) * 0,123]$

Characteristic


Light spring load = spring from stainless steel


More information

Further products

• Eccentric Mounting Bushings, for lateral plungers, smooth - INCH

Drawing





Erwin Halder KG

Order information

| Dir d ₁ | nensions d ₂ [inch] | Spring load F max. ¹⁾ ~ [lb] | Dimer I ₁ -0,04 [in: | nsions I ₂ | Stroke s [inch] | Location hole D H8 [inch] | max. | [oz] | Art. No. | | |
|--------------------------------------|--------------------------------|--|---|-------------------------|-----------------------|---------------------------------------|------|-------|------------|--|--|
| Pin: Thermoplastic/light spring load | | | | | | | | | | | |
| 1/2 | 0,315 | 11,2 | 0,525 | 0,547 | 0,09 | 1/2 | 176 | 0,117 | 2B150.0070 | | |


¹⁾ statistical average value

www.halder.com Page 1 of 2
Published on: 12.4.2019

Accessories

| | Dimensions d ₁ [inch] | [oz] | Art. No. |
|---------------|--|-------|------------|
| assembly tool | | | |
| | | | |
| | 1/2 | 2,321 | 22150.0832 |
| | | | |
| | | | |

Application example



www.halder.com Page 2 of 2
Published on: 12.4.2019