Lateral Plungers · smooth, without seal, with female thread - INCH



Product Description

To be used for positioning and applying pressure, e.g. during painting and sandblasting.

Material

Body

Aluminium

Threaded washer

· Steel, blackened

Spring

• Steel, zinc-plated by galvanization

Assembly

Formula for calculating the center distance for the mounting hole:

 $I_0 = z/2 + w + x$

 I_0 = center distance,

y = workpiece height,

w = workpiece length,

x = stroke

z = stop diameter

Calculation dimension x for workpieces: x = $d_2/2 - s$

Installation by pressing in.

Characteristic

Heavy spring load = spring from steel, zincplated by galvanization

More information


Notes


Individual set screws can be screwed in the plate with threaded hole.

Further products

· Eccentric Mounting Bushings, for lateral plungers, smooth - INCH

Drawing





Erwin Halder KG

Order information

Dimensions		Spring	Dimensions					Stroke	Location		I	Art. No.
d ₁	d ₂	load F max. ¹⁾	d ₃ +0,008	I ₁ -0,04	l ₂	l ₃	l ₄	s	hole D H8	max.	_	
[inch]		[lb]			[inch]	'		[inch]	[inch]	[°F]	[oz]	
heavy sprii	ng load											
7/16	8-32	22,5	0,248	0,433	0,1	0,177	0,047	0,063	7/16	482	0,096	2B150.1022

¹⁾ statistical average value

www.halder.com Page 1 of 2 Published on: 12.4.2019

Accessories	Dimensions d ₁	ň	Art. No.
	[inch]	[oz]	
assembly tool			
	7/16	1,749	22150.083



www.halder.com Page 2 of 2
Published on: 12.4.2019