# **Lateral Plungers** smooth, with seal, with female thread - INCH 2B150.1141



## **Product Description**

To be used for positioning and applying pressure, e.g. during painting and sandblasting. Sealed against chips and dirt.

#### Material

Seal • CR

Body

- Aluminium
- Threaded washer
- Steel, blackened

# Spring

Steel, blackened

## Assembly

Formula for calculating the center distance for
the mounting hole:
$I_0 = z/2 + w + x$ ,
$I_0$ = center distance,
y = workpiece height,
w = workpiece length,
x = stroke,
z = stop diameter
Calculation dimension x for workpieces: x =
d <sub>2</sub> /2 - s
Installation by pressing in.

#### Characteristic

Standard spring load = spring from steel, blackened

#### More information


## Notes

Individual set screws can be screwed in the plate with threaded hole.

## **Further products**

 Eccentric Mounting Bushings, for lateral plungers, smooth - INCH

# Drawing



# Order information

Dimensions		Spring	Dimensions					Stroke	Location		T.	Art. No.
d1	d <sub>2</sub>	load F max. <sup>1)</sup> ~	<b>d</b> <sub>3</sub> +0,008	<b>Ι</b> <sub>1</sub> -0,04	I <sub>2</sub>	I <sub>3</sub>	I4	S	hole D H8	max.		
[inch]		[lb]	[mm]	[mm] [inch]				[inch]	[inch]	[°F]	[oz]	
standard	standard spring load											
5/8	1/4-20	34	0,401	0,709	0,453	0,295	0,079	0,126	5/8	230	0,317	2B150.1141

D H8

1) statistical average value

Accessories								
	Dimensions d <sub>1</sub>	ă.	Art. No.					
	[inch]	[oz]						
assembly tool								
	5/8	3,749	22150.0833					