Keylo Pro Filling Instructions

Recommended Needle Size	Ideal Fill Temperature	Capping Time
16 Ga (or ≤1.8mm)	122° - 140° F / 50° - 60°C	1½ minutes



Unpackage the Keylo Pro pods and make sure you have both the mouthpieces and tanks ready.



Place the empty pods vertically upright on a flat surface. **Caution:** Do not remove the silicone gasket during the filling process.



Preheat the oil to the correct temperature for your specific oil (i.e., $\leq 135^{\circ}$ F (or 57° C).



Fill the pods using an oil syringe or filling machine; the recommended needle size is 16 gauge (or ≤1.8mm).



Fill the oil according to the tank capacity, through the large circular filling hole on top of the pods. Keep the crescent-shaped hole on the side unobstructed to allow air to escape.

Caution: When using a needle, insert it to a depth of 3/4 of the oil tank and do not touch the bottom.



Keylo Pro Capping Instructions

Capping Time	Capping Method	Min Capping Force	Max Capping Force
1½ minutes	Manual or Machine	TBA	TBA



Secure the mouthpieces onto the tanks by aligning them vertically and applying even pressure.



Complete the capping within 1½ minutes of filling the oil. For oils with thinner consistencies, **cap them promptly to prevent leaking.**



For very thin oils: After filling and capping, invert the pods immediately and let them cool for about 30 minutes before placing them upright. This helps prevent excess oil from seeping into the ceramic core before use.



For very thick oils: Allow the vape pods to sit for 30 minutes to 24 hours after filling and capping to ensure the oil fully saturates the ceramic cores before use.



Store the final products in a dry, cool place away from direct sunlight. Storage temperatures should be between 68° - 77° F (or 18° - 25° C).

Additional Info:

- After filling, the ceramic coil of the Keylo Pro pods will absorb some of the oil; this can result in a noticeable reduction in oil volume (up to 10%) and create extra space in the tank.
- Keylo Pro pods are compatible with most capping machines.

For more information, please contact info@ikrusher.com