


# *Skinbased*<sup>®</sup>

## Heel Guide Installation

The OAC Heel Guide for the EA Universal Binding can bring increased stability to nearly any ski mounted with an EA Binding. Below are the mounting instructions. If mounting to a non-OAC ski, be sure to always consult the ski manufacture's own mounting guidelines, as well as check the screw length compared to the ski thickness before beginning the mounting process. In event of a discrepancy, always default to the ski manufacture's specifications.



1. Gently wipe down the binding and mounting area with a damp cloth and allow to dry.
2. Determine the position of the Heel Guide. Ideally, the Heel Guide should be centered under the binding's heel unit, with the binding set for the boot or shoe that it is most often used with. Please note that this does not have to be exact. If one pair of skis is used by many different sizes of footwear, simply find an average. In general, the distance between the binding's front-most screw and Heel Guide's front-most screw hole should be between 180 mm and 240 mm.
3. Using the provided mounting template or a mounting jig, drill the holes using a 4.1x11 mm drill bit.
4. Apply a small amount of 2-part epoxy to the screw holes.
5. Install the screws using a PZ3 screwdriver.
6. Allow epoxy to cure the recommended time.

You are now ready to ski!

- WE LIKE IT -

*Skinbased*<sup>®</sup>

- MO-HAIRY -