

iTechworld battery in safe mode:

If you have a charged battery (E.G. car battery) and jumper cables, follow the below steps in sequence to bring your iTechworld lithium battery out of safe mode.

- Disconnect all loads/inputs from the iTechworld battery.
- Connect the iTechworld battery in parallel to a different battery (battery number 2)
- Cross reference the voltage on each battery now they are in parallel – they should both now read a similar voltage.
- Connect an AC to DC charger to the iTechworld battery and allow it to begin charging. We recommend a three stage 20 amp or higher charger.
- When the charger begins to charge the iTechworld battery, disconnect battery number 2.
- The charger should continue to charge the iTechworld battery, bringing it out of safe mode.
- Allow the charger to fully charge the battery.

If you have a portable Jump Starter, follow the below steps in sequence to bring your iTechworld lithium battery out of safe mode.

- Disconnect all loads/inputs from the iTechworld battery.
- Connect the Jump Starter cables to the battery (Positive to Positive, Negative to Negative)
- Connect an AC to DC charger to the iTechworld battery. We recommend a three stage 20 amp or higher charger.
- Activate the jump starter to supply power to the iTechworld battery. The charger will now detect the battery and begin to charge.
- When the charger begins to charge the iTechworld battery, disconnect the Jump Starter from the battery.
- The charger should continue to charge the iTechworld battery, bringing it out of safe mode.
- Allow the charger to fully charge the battery.