

ROCK

Quick Installation Guide

AX1800 Wi-Fi 6 Dual-Band USB Adapter
Model No. U1 / U1A

In the box

- Wireless USB adapter x 1
- Quick Installation Guide x 1

For U1A, a USB extension cable is provided.


1 Install the wireless USB adapter (Windows 10 supported)




Tips
If a wireless adapter has already been installed on your computer before, please uninstall the existing wireless adapter driver first. For detailed steps, see Appendix 1.

1 Install the wireless USB adapter.

- For U1, plug in your wireless USB adapter to a USB port on your computer.



- For U1A, plug one end of the USB extension cable into the wireless USB adapter and the other end into the USB port on your computer.




2 Double-click the **This PC** icon.




Tips
If you cannot find the This PC icon, please add the icon to your desktop first. For detailed steps, see Appendix 2.


3 Double-click **rock space**.



4 Double-click **Setup.exe**, and then install the wireless USB adapter according to the prompts.




Wait a moment until the initialization finishes. Now you can connect your computer to the Wi-Fi network.




2 Connect to the Wi-Fi Network (Windows 10 is used as an example)


- 1 Click in the bottom right corner of your screen, select the desired Wi-Fi network, and then click **Connect**.



- 2 Enter the wireless password if the network is encrypted, click **Next**, and then follow the system prompts.



Connected successfully.




Appendix 1: Uninstall the existing wireless adapter driver on your computer

Perform the following steps (Windows 10 is used as an example):

- 1 Click in the bottom left corner of your screen, and then click .



- 2 Click **Apps**.




- 3 Find and uninstall any other installed wireless adapter drivers.


Appendix 2: Add the This PC icon to your desktop

Perform the following steps (Windows 10 is used as an example):


- 1 Right-click anywhere on your desktop and select **Personalize**.



- 2 Select **Themes** from the left sidebar, and then click **Desktop icon settings**.



- 3 Check **Computer** and click **OK**.



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device is for indoor usage only.
Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Radiation Exposure Statement
This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules.
Caution:
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



Operating frequency:

2.4 GHz: 2402-2480 MHz
5 GHz: 5150-5350 MHz, 5470-5725 MHz, 5725-5850 MHz
NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

Operating Temperature: 0°C-40°C

Operating Humidity: (10%-90%) RH, non-condensing



RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

Deutsch

1 Installieren Sie den drahtlosen USB-Adapter (Windows 10 unterstützt)



Tipp
Wenn bereits ein drahtloser Adapter auf Ihrem Computer installiert ist, deinstallieren Sie bitte zuerst den vorhandenen Treiber für den drahtlosen Adapter.

2 Installation des drahtlosen USB-Adapters.

- Stecken Sie den drahtlosen USB-Adapter direkt in den USB-Anschluss Ihres Computers.
- Wenn ein USB-Verlängerungskabel mitgeliefert wird, verwenden Sie bitte das USB-Verlängerungskabel, um den drahtlosen USB-Adapter mit dem USB-Anschluss Ihres Computers zu verbinden.

3 Doppelklicken Sie auf das Symbol **Dieser PC**.



Tipp
Wenn Sie das Symbol **Dieser PC** nicht finden können, fügen Sie das Symbol zunächst zu Ihrem Desktop hinzu.

4 Doppelklicken Sie auf **rock space**.

- 1 Doppelklicken Sie auf **Setup.exe**, und installieren Sie den drahtlosen USB-Adapter gemäß den Anweisungen.

Warten Sie einen Moment, bis die Initialisierung abgeschlossen ist. Jetzt können Sie eine Verbindung mit dem WLAN-Netzwerk herstellen.

2 Verbinden mit WLAN (Windows 10 als Beispiel)

- 1 Klicken Sie auf in der unteren rechten Ecke Ihres Bildschirms, wählen Sie das gewünschte WLAN-Netzwerk aus und klicken Sie dann auf **Verbinden**.
- 2 Wenn das drahtlose Netzwerk verschlüsselt ist, geben Sie sein drahtloses Passwort ein, klicken Sie auf **Weiter** und folgen Sie dann den Systemaufforderungen.

Die Verbindung wurde erfolgreich hergestellt.

VEREINFACHTE EU-KONFORMITÄTSERKLÄRUNG

Hiermit erklärt SHENZHEN HECHUANG YOUSU TRADE CO., LTD., dass der Funkanlagentyp U1 & U1A der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar:
<https://rockspaceworld.com/pages/support>

Español

1 Instale el adaptador inalámbrico USB (Compatible con Windows 10)



Consejos
Si ya se ha instalado algún adaptador inalámbrico en su computadora anteriormente, por favor desinstale los controladores del adaptador inalámbrico primero.

2 Instale el adaptador inalámbrico USB.

- Conecte el adaptador inalámbrico USB al puerto USB de su computadora.
- Si se provee un cable de extensión USB, por favor utilice el cable de extensión USB para conectar el adaptador inalámbrico USB al puerto USB de su computadora.

3 Haga doble clic en el icono de **Este Equipo**.



Consejos
Si no puede encontrar el icono de **Este Equipo**, por favor añada el icono a su escritorio primero.

4 Haga doble clic en **rock space**.

- 1 Haga doble clic en **Setup.exe**, e instale el adaptador inalámbrico USB acorde a las instrucciones.

Espere hasta que termine la inicialización. Ahora podrá conectarse a la red Wi-Fi.

2 Conéctese a una red Wi-Fi (Se utiliza Windows 10 como ejemplo)

- 1 Haga clic en en la esquina inferior derecha de la pantalla, seleccione la red Wi-Fi deseada y haga clic en **Conectar**.
- 2 Si la red inalámbrica se encuentra encriptada, ingrese la contraseña inalámbrica, luego haga clic en **Siguiente** y siga las instrucciones del sistema.

Conectado correctamente.

DECLARACIÓN UE DE CONFORMIDAD SIMPLIFICADA

Por la presente, SHENZHEN HECHUANG YOUSU TRADE CO., LTD., declara que el tipo de equipo radioeléctrico U1 & U1A es conforme con la Directiva 2014/53/UE.
El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente:
<https://rockspaceworld.com/pages/support>

Français

1 Installer l'adaptateur USB sans fil (Pris en charge par Windows 10)



Astuces
Si un adaptateur sans fil a déjà été installé sur votre ordinateur auparavant, veuillez d'abord désinstaller le pilote de l'adaptateur sans fil actuel.

2 Installer l'adaptateur USB sans fil.

- Connecter l'adaptateur USB sans fil au port USB de votre ordinateur.
- Ou, si le câble d'extension USB est fourni, utilisez celui-ci pour connecter l'adaptateur sans fil USB au port USB de votre ordinateur.

3 Cliquez deux fois sur l'icône **Ce PC**.



Astuces
Si vous ne trouvez pas l'icône **Ce PC**, ajoutez-la d'abord à votre bureau.

4 Cliquez deux fois sur **rock space**.

- 1 Cliquez deux fois sur **Setup.exe**, puis installez l'adaptateur USB sans fil en suivant les instructions.

Patiencez jusqu'à ce que le démarrage soit terminé. Vous pouvez à présent vous connecter au réseau Wi-Fi.

2 Se connecter au réseau Wi-Fi (Windows 10 est utilisé ici à titre d'exemple)

- 1 Cliquez sur dans le coin inférieur droit de votre écran, choisissez le réseau Wi-Fi de votre choix, puis cliquez sur **Se connecter**.
- 2 Si le réseau sans fil est crypté, entrez le mot de passe, puis cliquez sur **Suivant** et suivez les instructions du système.

Connexion réussie.

DECLARATION UE DE CONFORMITE SIMPLIFIEE

Le soussigné, SHENZHEN HECHUANG YOUSU TRADE CO., LTD., déclare que l'équipement radioélectrique du type U1 & U1A est conforme à la directive 2014/53/UE.
Le texte complet de la déclaration UE de conformité est disponible à l'adresse Internet suivante:
<https://rockspaceworld.com/pages/support>

Italiano

1 Installare l'adattatore USB wireless (Windows 10 supportato)



Suggerimenti
Se l'adattatore wireless è già stato installato sul computer in precedenza, disinstallare prima il driver dell'adattatore wireless esistente.

2 Installare l'adattatore USB wireless.

- Collegare l'adattatore USB wireless direttamente alla porta USB del proprio computer.
- Oppure, se viene fornita una prolunga USB, utilizzare quest'ultima per collegare l'adattatore wireless alla porta USB del computer.

3 Fare doppio clic sull'icona **Questo PC**.



Suggerimenti
Se non riesce a trovare l'icona **Questo PC**, si prega di aggiungere prima l'icona al desktop.

4 Fare doppio clic su **rock space**.

- 1 Fare doppio clic su **Setup.exe**, e installare l'adattatore USB wireless in base alle istruzioni.

Attendere fino al termine della configurazione. Ora può connettersi alla rete Wi-Fi.

2 Connettere al Wi-Fi (Windows 10 usato come esempio).

- 1 Fare clic su su nell'angolo in basso a destra dello schermo, selezionare la rete Wi-Fi desiderata, e fare clic su **Connetti**.
 - 2 Se la rete wireless è crittografata, immettere la relativa password wireless, fare clic su **Avanti** e seguire le istruzioni evidenziate dal sistema.
- Connessione riuscita.

DICHIARAZIONE DI CONFORMITÀ UE SEMPLIFICATA

Il fabbricante, SHENZHEN HECHUANG YOUSU TRADE CO., LTD., dichiara che il tipo di apparecchiatura radio U1 & U1A è conforme alla direttiva 2014/53/UE.
Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet:
<https://rockspaceworld.com/pages/support>

Service and Support

To check the full list of ROCK network devices or learn more about the device (such as the setup video and installation guide), visit <https://rockspaceworld.com> or simply scan the QR code below.



Shenzhen Hechuang YouSU Trade Co., Ltd.
16/F, Block A, Zhongguan Times Square, No. 4168 Liuxian Avenue, Pingshan Community, Taoyuan Square, Nanshan District, Shenzhen, Guangdong, China
Website: <https://rockspaceworld.com>
Email: info@rockspace.cc
Tech Support:
Email (US): techsupport@rockspace.cc
Telephone (US): +1 (833) 816-6558
Email (EU): cs@rockhomelife.com
Telephone (UK): +44 8082737556
Service Time: EST 10:00 - 21:00 / CET 16:00 - 24:00 from Monday to Friday



CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.
Operations in the 5.15-5.25GHz band are restricted to indoor use only.
NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.
Declaration of Conformity
Hereby, SHENZHEN HECHUANG YOUSU TRADE CO., LTD. declares that the radio equipment type U1 & U1a is in compliance with Directive 2014/53/EU.
The full text of the EU declaration of conformity is available at the following address:
<https://rockspaceworld.com/pages/support>

Operating Frequency:

2.4 GHz: EU/2400-2483.5 MHz (CH1-CH13)
5 GHz: EU/5150-5250 MHz (CH36-CH48)
ERP Power (Max.):
2.4 GHz < 20 dBm
5 GHz < 20 dBm