Prime A Pac America's original pre-packaged concrete pump primer, is the first choice among line pumpers for its oatmeal-like consistency that works on long runs, rubber hoses and difficult set-ups. Just one pail of this bentonite clay based formula replaces 18 - 94lb. bags of Portland cement. **Prime-A-Pac** is the closest substitute for cement slurries. Not for use in structural concrete. It is available in 2lb. bags.

Features & Benefits:

- Bentonite clay based
- Closest substitute for cement slurries
- Each 2lb. bag replaces a 94lb. bag of Portland Cement

Available sizes	
Box (18 sachets)	32 oz. / 907 gr.
Pail (18 sachets)	32 oz. / 907 gr.
Drum (180 sachets)	32 oz. / 907 gr.
Skid (648 sachets)	32 oz. / 907 gr.

Instructions

Step 1. Mix:
• Empty one bag into five-gallon bucket and half fill with water.
• Stir for one minute.
• Fill remainder of bucket with water.
• Stir for one minute.
• Let mix stand for at least 15 to 20 minutes.

Step 2. Prime Pump:
(determine situation that best describes your pump)
• If the pump has a priming port (CAPS), pour into primer port just ahead of ready-mix.

If primed through the hopper:
For vertical intake ports (gate or rock valve):
• Fill water in hopper high enough for intake parts to charge as pump cycles.
• Pour the mixed Prime-A-Pac into hopper so the prime is charged in the system ahead of the ready-mix
For horizontal intake ports (ball or flapper valve):
• Fill water in hopper as necessary in order to allow the port or ports to charge as pump cycles.
• Pour the mixed Prime-A-Pac directly into intake port just ahead of the ready-mix.

If primed directly in the hopper:
• Pour at least 5 gallons of water into hopper.
• Pour one bag of Prime-A-Pac primer into hopper and cycle pump in reverse for 15 to 20 strokes.
• Let stand at least 10 minutes prior to priming system.
• Charge prime into system ahead of ready-mix.
How much to use?
Normally, one bag (2 pounds) for each 100 feet of 5" system.

Best results:
Pre-mix in a 5-gallon pail the night before