VISUAL COMFORT & CO.


STUDIO COLLECTION

NOEMIE LARGE SCONCE

KSW1142







FIXTURE PARTS

- A. Junction Box
- **B. Junction Box Wires**
- C. Fixture Wires
- D. Wire Nuts
- E. Mounting Plate
- F. Mounting Screws
- G. Ground Screw H. Fixture Screws I. Fixture Base
- J. Fixture Sockets
- K. LEDG9 T4 Bulbs (Not Included)
- L. Fixture Globes/Shades

INSTRUCTIONS

I. Preparing the Fixture

- 1. Separate the mounting plate from the fixture base by removing the fixture screws.
- 2. Install the mounting plate to the junction box and secure it using mounting screws.

II. Wiring the Fixture

- 1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
 - 2. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate, which the ground wire should be tightly wrapped around or a house wire (green or bare copper wire without insulation).
- 3. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
 - a) Hot fixture wire (black) and hot power line wire from the junction box (hot to hot)
 - b) Neutral fixture wire (white) and neutral power line wire from the junction box (neutral to neutral)
- 4. Carefully tuck all the wires behind the mounting plate into the junction box.

III. Installing the Fixture

- 1. Mount the fixture onto the mounting plate and secure it in place by tightening the fixture screws.
- 2. Install the bulb into the socket, referring to the label on the socket for Max Wattage information.
- 3. Affix the globes/shades onto the fixture.