



JackRabbit XG Owner's Manual

Contains important info about your JackRabbit
For instructional videos and answers to frequently asked
questions, scan this QR code to visit the JackRabbit.bike
support page at:

<https://jackrabbit.bike/support>




Record your JackRabbit information here:


Frame Color:_____ Serial Number:_____

Purchase Date:_____ Purchase Location:_____

XG OVERVIEW



DISPLAY OVERVIEW



ASSEMBLY INSTRUCTIONS

Your JackRabbit XG is pre-assembled and requires a few steps to get it ready to ride.

JACKRABBIT XG BOX CONTENTS

- JackRabbit XG micro ebike
- AC battery charger
- Charging adapter (only needed if charging battery outside of bike).

ASSEMBLY STEPS:

1. Remove all contents from the carton (including battery charger). Cut any zip ties and remove packaging padding.
2. Rotate the front wheel to riding position ensuring the left brake cable stays only on the left side, moving directly from the brake lever to the brake caliper.
3. Insert the handlebars into the stem hole vertically and then rotate clockwise to the proper riding position.
4. Align the opening on the handlebar clamp with slot in the stem base. Turn knob on handlebar clamp clockwise to tighten and then push clamp towards stem to secure. Improper attachment especially from over, or under-tightening may result in damage to the stem base or handlebars leading to a loss of control, serious injury, or death. Check to make sure that the handlebars are secured to the frame and cannot move freely before riding the JackRabbit.
5. Squeeze the front and rear brake levers to confirm that the brake pads contact the rotors.
6. Set seat height so feet are flat on the ground when seated. Tighten the seat post clamp the same way as handlebar clamp.
7. Fold down the footrests.
8. Check the tires' air pressures. All tires lose air pressure over time. 40 psi is the minimum. Inflating to 65 psi (maximum) will result in lower rolling resistance and increased riding range.

MAINTENANCE:

For regular bike maintenance tasks like repairing tire punctures, adjusting brake cables, levers, and rotors, or fixing wire connections, please visit a nearby bike shop. In case the local shop cannot assist you, feel free to reach out to us at info@jackrabbit.com, and we'll do our best to help.

FIRST RIDE GUIDANCE

(Learning to ride JackRabbit is easy.)

First: top up the batteries by plugging charger into the JackRabbit underneath at the rear and add air to the tires.

Start out using it like a child's balance bike:

- Before riding, test out the brakes. Make sure you feel comfortable with the reaction and pay close attention to the front brakes locking up.
- Simply push with your legs and glide.
- Ride with the balls--not heels or arches--of your feet on the footrests.
- You'll be surprised how fast you can coast and glide on flat ground.
- Sit comfortably and try not to lean on the handlebars -just use them for steering.
- Use your legs as shock absorbers by pressing down through your feet and lifting your tush off the seat when encountering rough road conditions.

After you get a feel for the braking and handling characteristics:

- Long press the power button on the throttle control to turn on the power.
- Begin in ECO mode and get used to the acceleration before advancing to other power modes. Inexperience with may result in injury, or death.
- With both hands on the handlebars, push off with your foot to get the bike rolling.
- Lightly push your thumb down on the throttle to get the motor going. Just a little bit at first!
- Release your thumb anytime to coast.
- Not much throttle is needed. "Pulsing" and glide-coasting is the best way to travel over flat ground.
- You can quickly and easily put both feet on the ground at any time--something you can't do on a bicycle or scooter.

HOT TIPS & TRICKS

Charge the batteries in the JackRabbit by plugging the charger directly into the JackRabbit Charging Port underneath the main tube near the rear.

The ports on the side of the main tube are for lights, **DO NOT ATTEMPT TO PLUG THE CHARGER IN THEM.**

The adapter that comes with the charger is only needed for charging batteries when they are removed from the frame.

To remove a battery for using a spare battery or when flying with JackRabbit: turn the knob below where the battery is located, turn 90 degrees counter clockwise, and then use two hands to gently pull the battery straight up.

To insert a spare battery, make sure the lock is in the open position then use both hands to lower battery straight down. Jiggle a bit to insert until battery top is flat on top of JackRabbit. No pressure is needed! Do not use force! Once fully inserted, rotate the knob 90 degrees clockwise.

The XG is not designed for off-road riding. But in the event you encounter less-even terrain such as rough road conditions, remember to use your legs as shock absorbers by pressing down through your feet and lifting your tush off the seat. Remember you can always dismount and walk the XG at any point the terrain becomes too rough or unpredictable.

Try Walk Mode! Watch our videos to see how!

Buy cool accessories at **www.jackrabbit.bike**

Contact us anytime for answers and additional information about anything in this booklet at **info@jackrabbit.bike**

Ride safe, be respectful of others around you when riding, and HAVE FUN!

—JackRabbit Team

FOR SAFE RIDING PLEASE HEED THESE SAFETY PRECAUTIONS AND WARNINGS



THIS PRODUCT IS INTENDED FOR ADULT USE ONLY. JACKRABBIT XG IS FUN, BUT NOT A TOY. NEVER PERMIT CHILDREN UNDER THE AGE OF 18 TO OPERATE IT.



RIDING AROUND CARS, PEDESTRIANS, OTHER CYCLISTS OR POTENTIAL HAZARDS BEFORE YOU ARE ABLE TO SAFELY DO SO COULD RESULT IN SEVERE INJURY OR EVEN DEATH.



NEVER RIDE UNDER THE EFFECTS OF ALCOHOL OR DRUGS.



TO AVOID UNINTENTIONAL MOVEMENT PUT YOURSELF IN THE PROPER RIDING POSITION, SEATED ON YOUR JACKRABBIT XG BEFORE PUSHING THE THUMB THROTTLE.



STOPPING YOUR JACKRABBIT XG: RELEASE THUMB PRESSURE ON THE THROTTLE AND APPLY THE HAND BRAKES UNTIL YOU COME TO A COMPLETE STOP.



JACKRABBIT XG'S TOP SPEED IS LIMITED TO 20 mph. HOWEVER, IT IS POSSIBLE TO EXCEED THIS SPEED WHILE COASTING DOWNHILL. PLEASE EXERCISE CAUTION IN THESE SITUATIONS.



DO NOT EXCEED THE WEIGHT LIMIT OF 275 lbs (128 kg).



JACKRABBIT XG IS INTENDED FOR SINGLE RIDER USE ONLY.



ALWAYS WEAR PROTECTIVE HEADGEAR!



RIDING JACKRABBIT XG IN FOUL WEATHER CONDITIONS (RAIN, HAIL, SLEET, SNOW, ETC.) IS NOT RECOMMENDED



DO NOT RIDE AT NIGHT (IN THE DARK) WITHOUT ILLUMINATING FRONT AND REAR LIGHTS.



BATTERY, MOTOR, AND ELECTRICAL SYSTEMS WARNING: RISK OF FIRE AND ELECTRIC SHOCK – NO USER SERVICEABLE PARTS.
FOR SERVICE: INFO@JACKRABBIT.BIKE