

E-mail: Support@petnannystore.com

Website: www.petnannystore.com



AQQA Aquarium AC Air Pump



The AQQA Aquarium AC Air Pump provides sufficient bubbles at home for your aquariums.

1. PRODUCT FEATURES

Adjustable air output and high volume: The air pump with adjustable air output can be used in tanks of different sizes and its strong airflow can provide sufficient oxygen for your fish tank.


Cushioning Silicone Feet and Low Noise: ≤ 40dB low noise due to the magnet-driven design to generate air flow in the space room, and the air pump has silicone feet to further reduce the noise.

Beautiful and Unique Appearance: Trendy black matt finish with mirror polish appearance in the middle. ABS material is very durable.

Please pay attention to the below important reminder before using:

Picture 1: If the air pump is placed below the water surface level in the tank, you must install check valves to the air pump. If you do not use a check valve, this could make water drain back to the pump resulting in pump damage.

Picture 2: Place the air pump 25 cm (approximately 10 inches) higher than the surface of water in the tank in order to avoid water back flow.



2.PRODUCT PARAMETERS:

Dimension	Power	Voltage	Sound	Air Flow	Pressure	Depth	Cord Length	Application
3.9"x3.15"x1.6" 10x8x4CM	3.5W	110-120V/60Hz	≦40dB	3L/min	0.01MPa	2Ft 0.6M	5.9Ft 1.8m	Up to 50Gal
	5W	220-240V/50Hz		5L/min	0.02MPa	5.9Ft 1.8M		Up to 160Gal

3. ATTENTION:

- ✓ Please read this manual carefully before use and follow in strict accordance with the manual.
- ✓ Install the air pump with check valves or place the air pump 25cm (approximately 10 inches) higher than the surface of tank water in order to avoid water back flow and potential damage to the pump.
- ✓ Place the air pump on a flat surface. Putting a towel or rubber mat under the pump can further reduce the sound.
- ✓ Keep the air pump away from water as the air pump is not waterproof.
- ✓ Keep the air pump away from open flame in order to avoid accidents.
- ✓ Unplug the air pump and contact the seller if the air pump is making abnormal sounds, is overheating, or has no air output.

OPENING THE AIR PUMP WILL VOID THE WARRANTY

- ✓Please soak the air stones for 1-2 hours before first use to get perfect bubbles with this pump.
- ✓ Please note that airflow loss is usually caused by clogged air-stone. Air stones clogging can happen over time and usually results from algae, floating debris, and mineral deposits accumulated in the pores. If you notice a diminished air flow, try blowing through the air-stone yourself. If it is difficult, replace the air-stone.
- ✓ Please unplug the air pump from power source before any maintenance is performed.
- ✓ Operating temperature range for this air pump is between 33.8~95°F.
- ✓ Maximum depth of water for the attached air stone is 6.5 feet.

4. PACKAGE INCLUDES:

1 x aquarium air pump

2 x air stone

2 x air tube

2x check valve

1x Tee connector

2x extension connector

1x use manual

5.WARNING: To avoid possible electrical shock, do not immerse the pump in water. If the pump falls into the water, or becomes wet, do not touch it until you have unplugged it. Basic safety precautions should be observed including the following:

CAUTION:To prevent possible electrical shock resulting from water back-siphoning, pump should be used with a check-valve or positioned higher than the tank's water level.

- 1.Read and follow this user manual strictly.
- 2.DANGER-To avoid possible electric shock, special care should be taken. For each of the following situations, do not attempt to repair yourself; return the pump to an authorized service facility for maintenance or discard the pump.
- A.If the pump falls into the water, do not touch it. First unplug it, then retrieve it. If electrical components of the pump get wet, unplug the pump immediately.
- B.Carefully examine the pump after installation. It should not be plugged in if there is water on parts not intended to be wet.
- C.Do not operate the pump if it has a damaged cord or plug, if it is malfunctioning, or if it is dropped or damaged in any manner. The power cord of this pump cannot be replaced, if the cord is damaged, the pump should be discarded.
- D.To avoid the possibility of the pump plug getting wet, position aquarium and stand to one side of a wall mounted outlet to prevent water from dripping onto the outlet or plug. A "drip loop", shown in the figure below, should be arranged by the user for each cord connecting the pump to the outlet. The "drip loop" is the part of the cord below the level of the outlet, or the connector. If an extension cord is used, use a drip loop to prevent water traveling along the cord and coming in contact with the

outlet. If the plug or outlet does get wet, DO NOT unplug the cord. Disconnect the fuse to the circuit breaker that supplies power to the pump. Then, unplug and examine for the presence of water in the outlet. If you are unsure, consult a certified electrician.



- 3. Close supervision is necessary when the pump is used near children.
- 4. To avoid injury, do not contact moving or hot parts.
- 5. Always unplug the pump from the outlet when not in use, before putting on or taking off parts, and before maintenance or placing hands in the water. Never yank the cord to pull plug from outlet. Grasp the plug and pull gently to disconnect.
- 6.Do not use the pump for other than its intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition.
- 7.Do not install or store the pump where it will be exposed to weather or to temperatures below freezing. This pump is suitable for use in water temperatures less than 95 $^{\circ}$ F.
- 8. Make sure the pump is securely installed before operating.

- 9.Read and observe all the important notices on the pump.
- 10.If an extension cord is necessary, a cord with a proper rating should be used. A cord rated for less amperes or watts than the appliance rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
- 11. The pump is intended FOR HOUSEHOLD USE ONLY.
- 12. SAVE THIS USER MANUAL.

6. WARRANTY:

- 1. 1-year free warranty.
- 2. 1-month free return.
- 3. Free replacement for 3 months.

7.DISPOSAL

Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary. This product must not be disposed together with the domestic waste. This product has to be disposed at an authorized place for the recycling of electrical and electronic appliances. By collecting and recycling waste, you help save natural resources. Please, make sure the product is disposed in an environmentally friendly way.