

Instructions



Thank you for choosing IZIMINI. Selected materials, maximum precision and extensive test procedures ensure the highest quality and safety. Our goal is to bring simple, practical and stylish accessories to make your life easy and make the most of our unique outdoor lifestyle in Australia. At IZIMINI, we believe that everyday with our minis should be fun and colourful.


IZIMINI

Components


a Folding Booster Seat



b Tray



c Chair Straps




d Travel Bag




IZIMINI

Assembly


1 Remove tray and booster.




2 Pull open.



3 Squeeze levers on tray and slide onto booster.




NOTE: Before use, ensure that the tray connection is secure.



NOTE: Before use, press down on seat to ensure legs and seat fully open.

IZIMINI

Child restraint system





WARNING: Prevent serious injury or death from falls or sliding out. Always use restraint system.

IZIMINI

Securing booster to chair

1 Attach strap to rear leg and one strap to cross bars on booster's side.

2 Slide strap through buckle.







3 Repeat with two remaining straps on opposite side of chair.

IZIMINI

Securing booster to chair cont.

1 Place booster on chair.

2 Fasten clips around chair back and underneath chair seat




3 Be sure to tighten straps.

IZIMINI

Pack away

1 Squeeze levers on tray and slide off booster.

2 Lift seat and push closed.



3 Slide tray and booster into travel bag.



IZIMINI

Cleaning and maintenance

Before each use, inspect the booster seat for damaged hardware, loose joints, missing parts or sharp edges. Do not use booster seat if any parts are missing, torn or broken.

To clean booster seat and chair straps: Wipe clean with a damp cloth or sponge, using mild soap and clean warm water. Towel or air dry.

Tray: Dishwasher safe, top rack only.

IZIMINI

WARNING

PREVENT SERIOUS INJURY OR DEATH FROM SLIDING OUT, FALLING OR TIPPING OVER.

NEVER leave the child unattended or without supervision. ALWAYS use the restraint system and ensure it is correctly fitted before use. This product is not designed for children under 6 months or over 15kg. The tray is not designed to hold the child in the chair. Always use the safety belts. Prevent finger injury: unfold seat completely before use. Keep child away from seat when folding and unfolding. NEVER lift this product with your child in it. NEVER use this product as a car seat or bath seat, on a table or counter top, high chair, stool, swivel chair, folding chair, unstable chair or any other chair where the straps cannot secure it properly. DO NOT use in motor vehicles. ALWAYS check security to fit to adult chair before each use. USE ONLY on a chair whose seat dimensions are greater than those of the booster seat. ALWAYS use the four straps as described in "Securing booster to chair" section. NEVER allow child to push away from table. DO NOT use this product if it is damaged or broken or if any part is missing.

IZIMINI