

LED REGRESSED TRIMLESS MULTI-HEAD GIMBAL - 5 CCT SELECTABLE LR32200, LR32201, LR32202, LR32203, LR32204, LR32205, LR32206, LR32207

IMPORTANT: READ ALL INSTRUCTIONS BEFORE INSTALLING FIXTURES. RETAIN FOR FUTURE REFERENCE.

SAFETY: FOR YOUR SAFETY, THIS FIXTURE MUST BE WIRED IN ACCORDANCE TO LOCAL ELECTRICAL CODES AND ORDINANCES. ALL WORK SHOULD BE DONE BY A QUALIFIED ELECTRICIAN.

WARNING: MAKE CERTAIN POWER IS OFF FROM THE ELECTRICAL PANEL BEFORE STARTING INSTALLATION OR ATTEMPTING ANY MAINTENANCE. INDOOR INSTALLATION ONLY.

TOOLS REQUIRED: SAW, MEASURING TAPE, ELECTRICAL WIRING (USE TAPE AND GAUGE SUITABLE FOR APPLICATION TO CONNECT THE FIXTURES).

PRE-INSTALLATION:

1. Turn power OFF from the electrical panel before starting installation.
2. Locate a suitable position to place the fixture and open in accordance to the cut-hole dimensions (refer to Hole Cut Table for appropriate size)
3. Run electrical wire from the switch (power supply) through the mounting hole -use NMD90 Romex or BX cable.
4. Align the inside edge of the Zero clearance plaster frame to the drywall hole and screw in place (Fig. 1)
5. Plaster over the plaster frame, be careful not to fill past raised frame. (Fig. 2)

DRIVER WIRING:

1. Open the hardwire box swing cover and remove the appropriate knockout(s).
2. Insert the electrical supply cable through the knockout and secure with a cable connector (sold separately).
3. Using wire nuts, connect green ground wire of cable to green wire on box. Connect white wire of cable to white wire of box. Connect black wire of cable to black wire of box. (Fig. 3)
4. Place all wiring and connections back into the box and close the cover.
5. Insert hardwire box through the mounting hole. (Fig. 4)

FIXTURE INSTALLATION:

1. Connect the fixture to the hardwire box by inserting and twisting the male/female connectors. (Fig.3)
2. Insert the fixture to plaster frame, secure the lamp by twisting the fixture appropriately to the plaster frame (Fig.4)
3. Once assembly is complete, turn on power to confirm fixture is working properly.

HOLE CUT SIZE

- 1-Head Trimless 4 1/4" * 4 1/4" (108mm * 108mm)
- 2-Head Trimless 7 7/8" * 4 1/4" (200mm * 108mm)
- 3-Head Trimless 11 3/4" * 4 1/4" (298mm * 108mm)
- 4-Head Trimless 15 1/8" * 4 1/4" (388mm * 108mm)

