M75 Series


DrunkDeer®

Expert In Non-Mechanical Switch Keyboard

A75

User Manual

Magnetic Switch Keyboard



Package Content

```
A75 MS Keyboard *1
USB Type-C Cable *1
Dustproof Cover *1
Keycap Puller *1
Quick Guide *1
Extra Switch *2
```

A75 MS Keyboard



Quick Guide



Keycap Puller




Dustproof Cover



USB Type-C Cable



Wired Connection



For the devices with Type-C ports(Laptop, for example), you can connect the keyboard to the device with the Type-C cabledirectly.

How to restore the keyboard to default settings



You can restore the keyboard by key combination 'Fn2(Menu) + Esc' for **3 seconds**The backlight will blink red for 3 seconds and the keyboard will return to its default state.

How To Adjust The Actuation Sensitivity



1, Select the key(Example WASD)



2,Set Action Point
Set the point to activate a keypress

How To Set The Rapid Trigger Mode



3, Enable the Rapid Rrigger Mode



4, Key sensitivity setting (We Recommend that You Set the Sensitivity of the RT to 0.2MM)



5,Don't Forget to Click the 'Save to Keyboard' Button at the end

About The Magnetic Switch

Magnetic Switches utilize Hall Sensors to determine the distance a key is pressed by measuring the strength of the magnetic field.

It makes it possible to customize the trigger point (actuation point) to your preferred level of pressure and distance, accommodating all typing styles.


Whether you bottom out or barely touch the keys, we've incorporated adaptive typing to provide noticeable comfort improvement for everyone.

MS doesn't rely on physical contact, which can wear down the key over time. These switches can be pressed hundreds of millions of times.

This is vastly superior to the metal contacts of conventional switches.



How To Control The Backlight Effect




The backlight effect can be changed by key combination as follow:

Fn2 (Menu)+ Tab: Change the backlight color (Only for certain effects)

Fn2 (Menu)+ ←: Previous backlight effect Fn2 (Menu)+ →: Next backlight effect

Fn2 (Menu) + ↑ : Increase the backlight brightness
Fn2 (Menu) + ↓ : Decrease the backlight brightness

How To Switch The Operating Layout



The operating layout of the A75 can be changed by key combination as follow:


Fn2 (Menu) + M : Switch to the Mac OS

Under the MacOS layout, the function keys on F1 to F12 are available without other driver program.

Fn2(Menu)+ W : Switch to the Windows

Under the Windows layout, the function keys would retain original key value.

Control The Volume With The Knob



Whether it's MacOS or Windows layout, volume of the computer can be controlled directly by turning the knob.



You can also play or pause music/video by pressing the knob.



Specification

Keyboard Model: A75

Keyboard Size: 355mm* 140mm*45mm

Keyboard Weight: 715 + 20 g

Layout: ANSI 75%

Main Material: ABS(Keycaps, Case); PBT Keycaps (option);

Aluminum case (option)

Switch Type: DrunkDeer Magneitc Switch

System Available: Windows & Mac OS

Caution

Please DO NOT place the keyboard in a high-temp or strong magnetic environment.

We DO NOT recommend disassembling or modifying this keyboard.

Due to the characteristic of magnetic switches, abnormal environments such as severe impact,

high temperature, and strong magnetic fields may cause the keyboard to malfunction.

If you have other questions, please feel free to contact us with hello@drunkdeer.com or go to our official website www.drunkdeer.com for further information and help.

DrunkDeer®

Expert In Non-Mechanical Switch Keyboard

Magnetic Switch Series