

2017+ Chevrolet Colorado ZR2 Gas and Diesel Front Coilover Conversion



Parts List:

- (2) 14" Long, 3.0" ID Springs
- (2) Threaded Adjuster Assemblies
- (2) Threaded Perches
- (2) Metal Spring Isolators/Washers
- (2) Upper Spring Mounts
- (2) Lower Stem Washers
- (2) Stem Sleeves
- (4) Upper Spring Mount Bushings
- (2) Adjuster Punches

Tools Needed:

- 5mm allen
- 6mm wrench
- 10mm wrench
- 10mm socket
- 15mm wrench
- 15mm deep socket
- 18mm wrench
- 18mm deep socket
- 18mm ratcheting wrench
- 21mm wrench
- Spring Compressor
- Hammer and ballpeen hammer

Approximate Install Time: 3-6 Hours depending on skill and tools


Notes:

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- Never use impact wrenches or impact guns to install or remove shock absorber piston components, shafts and piston rod nuts

Installation:

- 1) Block the rear wheels, lift the front of the vehicle, and place on jack stands or use automotive lift
- 2) Remove front wheels
- 3) Remove front endlinks using 13mm socket/wrench and 15mm socket/wrench


4) Using 10mm wrench to hold hex and 21mm wrench, loosen tie rod but do not remove nut all the way



5) Using ballpeen and weighted hammer lightly tap tie rod are to break taper loose if necessary



6) Remove Tie Rod From Knuckle



7) Using 10mm socket, unbolt wheel speed sensor, located on back of knuckle



8) Using 18mm ratcheting box wrench, loosen all three top mount bolts, starting with the back one will be easiest



9) Use a 15mm deep socket to loosen the two bottom shock bolts



10) Loosen upper control arm ball joint using 18mm deep socket, you may need to use 18mm wrench and 5mm allen to avoid spinning the ball joint, DO NOT REMOVE all the way



11) Using a jack (or buddy) support the lower control arm and loosen the last few turns on the upper ball joint nut being careful not to let the knuckle hang on the brake line



12) The shock assembly can now be removed from the assembly

13) Replace nut on upper ball joint to hold knuckle while working on the shock off the truck




14) Place shock in appropriate spring compressor, DO NOT USE a spring compressor that is not rated for a spring of this rate

15) Once the spring is compressed, use a 15mm and 6mm wrench to loosen the top nut and remove the shock from the spring. Be sure to hang onto the nut and washer these will be resused later.

Notes before install:

- The threaded sleeve is difficult to adjust once on the truck
- Spring seat should be as close to desired height as possible before sliding onto the shock
- Full high below will yield 2.00" of lift with 550 lb/in on stock weight gas
- Full high below will yield 2.00" of lift with 600 lb/in on weighted gas
- Full high below will yield 2.00" of lift with 650 lb/in on stock weight diesel
- Full high below will yield 2.00" of lift with 700 lb/in on weighted diesel
- Moving the collar down 0.75" will lower the truck approx. 1" at the wheel
- There are 12 threads per inch, moving the collar down 9 threads will lower 1" at the wheel
- Lifting the vehicle more than 2.00" will result in rough ride, this is possible on the heavier rates if the vehicle is not running enough weight. A weighted truck is considered steel bumper and winch, not aluminum bumper even with winch
- Shocks ARE SIDE SPECIFIC the reservoirs are clocked slightly different to allow ample clearance to the CV boot when installed DO NOT MIX UP THE SIDES this will result immediate boot failures



16) Remove dust boot and discard, remove OEM spring seat and discard



17) Slide threaded body and adjuster over shock body, be sure to preset your threaded collar height, see notes on previous page

18) Place large metal washer (not pictured) onto the spring seat and provided flat washer onto shock shaft



19) Place provided bushing on top of washer, on shock shaft



20) Slide sleeve over shock shaft as shown



21) Place new spring and top hat into spring compressor as shown





22) Place bushing onto top hat as shown



23) Place OEM washer onto bushing as shown



24) Compress spring and slide shock with washer, bushing, and sleeve installed into spring and top mount. Be sure single bolt on top mount is oriented in same direction as DSSV Reservoir as shown. The closer these are lined up the easier reinstall will be



25) Tighten nut using 15mm and 6mm wrenches



26) Remove upper control arm ball joint nut and install shock assembly back into truck

27) Reinstall the upper ball joint into the knuckle and tighten with 18mm wrench and 5mm allen



28) Reinstall and tighten lower shock bolts using 15mm socket



29) Install provided nuts onto upper shock mounts and tighten using 15mm ratcheting box wrench



30) Reinstall mount for wheel speed sensor using 10mm wrench or socket



31) Reinstall and tighten tie rod ball joint using 10mm and 21mm wrenches



32) Reinstall front end links and tighten using 13mm socket/wrench and 15mm socket/wrench

33) Reinstall wheels

34) Recheck all bolts after 100 miles of driving

Enjoy!

Notes on adjustment:

- Adjustment should be done with the threads clean and clear of dirt, debris etc.
- Adjustment should only be done with the front of the vehicle jacked up
- Tools are provided but often a properly sized punch works great as well

RELEASE OF LIABILITY

I, the customer, do hereby release and forever discharge Level Up Suspension, their agents, employees, successors and assigns, and their respective heirs, personal representatives, affiliates, successors and assigns, and any and all persons, firms or corporations liable or who might be claimed to be liable, whether or not herein named, from any and all claims, demands, damages, actions, causes of action or suits of any kind or nature whatsoever, whether known or unknown, fixed or contingent, which I now have or may hereafter have or claim to have, as a result of or in any way relating to the following: Parts sold & installed by Level Up Suspension or parts sold & installed by end-user; any parts sold online, any parts sold online or installed by a re-seller, any parts installed by an installation shop.

It is understood and agreed that this payment is made and received in full and complete settlement and satisfaction of the aforesaid actions, causes of action, claims and demands; that this Release contains the entire agreement between the parties; and that the terms of this Agreement are contractual and not merely a recital.

Furthermore, this Release shall be binding upon the undersigned, and his respective heirs, executors, administrators, personal representatives, successors and assigns. This Release shall be subject to and governed by the laws of the State of California.

PRODUCT SAFETY WARNING: Level Up Suspension strongly recommends the installation of products be done by a certified mechanic. If this does not occur, be certain the person(s) installing the product read, understand and follow all instructions and warnings pertaining to the application before installation. Do not add, alter, or fabricate any factory or aftermarket parts to increase vehicle height over the intended height of the Level Up Suspension product purchased. Mixing component brands is not recommended.

Installation of suspension lift kits or any other lifting kits or devices will raise the center of gravity. For this reason, Level Up Suspension urges that extreme caution be used when encountering driving conditions which may cause vehicle imbalance. Furthermore, the driver's field of vision and judgment will not be as good due to the height of the vehicle. Due to the installation of larger tires, the speedometer will read slower than the actual speed being traveled and more distance will be required to stop the vehicle. It is the owner's responsibility to caution and warn any potential driver of the vehicle about these driving and handling conditions. Level Up Suspension will not be held liable or responsible for damages or personal injuries resulting from the use of lifting devices and or related products. The tires and rims should be changed to sufficiently increase the vehicle's total overall width and stability to help accommodate lifting devices.

Level Up Suspension aftermarket suspension products and accessories modify a vehicle for uses which exceed conditions anticipated by the vehicle manufacturer. The uses include the high performance demands required during off-road. These conditions vary in the degree of extremity and cannot be controlled by the vehicle or product manufacturer. If the components within the suspension system or accessories become worn due to frequent and/or extreme use, the safety and reliability of the vehicle is at risk. The maintenance of aftermarket equipment to ensure the vehicle occupants safety is entirely your responsibility. Do not purchase Level Up Suspension products unless you are willing to accept this responsibility. Do not install any Level Up Suspension products or accessories unless you feel competent at installing the product without causing present or future injury to yourself or other vehicle occupants; seek an authorized installation center.

Most states have some type of law limiting vehicle height. The amount of lift allowed, and how the lift can be achieved, varies greatly. Several states offer exemptions for farm and commercial registered vehicles. It is the vehicle owner's responsibility to check state and local laws to ensure that their vehicle will be in compliance. Level Up Suspension reserves the right to make changes in design, materials and specifications as deemed necessary without prior notice and without assuming obligation to modify any product previously manufactured. Obligation or liabilities will not be assumed with respect to similar products previously advertised.

This Release of Liability and Product Safety Warning has been read and fully understood by the undersigned and has been explained to me.