



DRAG RACING BRAKE
SYSTEM INSTALLATION
INSTRUCTIONS
001-0160
FRONT, EVO VII-IX

- Remove the existing brake components
- Ensure the spindle is clean and free of debris
- Scuff the pad swept area of the rotor with a rotor hone or 80 grit sandpaper. This allows the pad to seat to the rotor during break in.
- Lay the hat bowl side up and place the flat side of rotor on the hat.
- Apply blue Loctite to the 5/16-18 low head cap screws, fasten the rotor to the hats. Torque to 15 ft.-lbs.
- Mount the bracket to the spindle using the ¼" spacers to space the bracket from the spindle, use the supplied M12 hex bolts and washer.
- Slide hat and rotor assembly onto the hub and secure with studs.
- Slide the caliper over the rotor and mount it to the bracket. Snug the 3/8-16 bolts, lock washer and washer. Check for proper radial and horizontal clearance between the rotor and the caliper.
- Insert the brake pads and pad retaining pin, and hold the pads against the caliper housing. Spin the rotor assembly to check for contact between the rotor and brake pads. The F13 is a zero drag caliper and there should be no contact between the rotor and pads.
- If there is pad to rotor contact, determine which side is causing the interference. Shim the caliper or the bracket as needed using the supplied shim kit to center the caliper over the rotor for zero drag.
 - **What is required for one side of the car may not be the same as the other side. Check each side individually**
- Verify the pad material is sitting in the proper location in relation to top of the rotor [flush +/- .07"]
- Go back and tighten the caliper mounting hardware
- Connect the brake lines check for interference with any suspension or driveline components
- Bleed the entire brake system and verify proper caliper operation and release

Break-In

- All of our brake pads are pre-cured, which extends life and compound stability, and eliminates complicated bed-in procedure
- Take the vehicle out and verify proper brake operation at low speed before bed-in

-Bring the brakes up to operating temperature and ensure they are properly heated

*this may require some time and caution on the street

-you will feel the pedal come to you, and the brake torque output increase

- Allow the system to cool and the bed-in is complete

-If you observe material transfer to the rotors [dark streaking on the rotors], the system has not been fully bedded in.

If technical support and information is needed please contact us at 805-987-7867 or info@tbmbrakes.com