











TMBBRAKES






1974-1978 MUSTANG II WILWOOD PROSPINDLE FRONT XS3 STREET BRAKE KIT (012-0310)






Parts List

	<p>XS3 Rotor - 12.19 / 0.810 / 8 on 7.00"</p> <p>Part Number: 3-121981087-1</p>
	<p>XS3 Rotor - 12.19 / 0.810 / 8 on 7.00"</p> <p>Part Number: 3-121981087-2</p>
	<p>XS3 Rotor Adapter</p> <p>Part Number: 205-0001</p>
	<p>XS3 Rotor Adapter</p> <p>Part Number: 205-0001</p>
	<p>XS3 Caliper, 1.75" Diameter Piston, .810" Rotor</p> <p>Part Number: 3-202-XS3-1</p>
	<p>XS3 Caliper, 1.75" Diameter Piston, .810" Rotor</p> <p>Part Number: 3-202-XS3-2</p>
	<p>XS3 to ProSpindle Mustang II Caliper Bracket</p> <p>Part Number: 3-17-007</p>
	<p>XS3 to ProSpindle Mustang II Caliper Bracket</p> <p>Part Number: 3-17-007</p>
	<p>XS3 Replacement Pads (full set)</p> <p>Part Number: 6-0002HPS</p>






Hub Parts List

	Late Ford Hub Part Number: 8-0113
	Oil Seal Part Number: 011-6815
	Bearing Set Part Number: 011-A12
	Bearing Set Part Number: 011-A13
	1/2''-20 X 2'' Wheel Studs (10 Pack) Part Number: 11-9803






Rotor & Hub Mounting Hardware

	16	Rotor Bolt, 5/16-18 X 3/4''
	16	Rotor Flat Washer, 5/16''
	10	Rotor Adapter Bolt, 7/16-14 x 1'' SHCS

Caliper Mounting Hardware

	4	Bolt, 3/8-24 X 1
	4	Lock Washer, 3/8"
	4	Flat Washer, 3/8"
	10	Steel Shim, .010TK, 3/8 ID, 5/8 OD
	10	Steel Shim, .031TK, 3/8 ID, 5/8 OD

Caliper Bracket Mounting Hardware

	4	7/16-20 X 1.25", FHCS
	2	7/16-14 X 3", FHCS
	2	Nylon Lock Nut, 7/16-14
	2	Spacer, 19.05mm OD x 12.9mm ID, 9/16"
	2	Spacer, 3/4 OD x 1/2 ID, .093"

Step 1: Remove the existing brake components and ensure the spindle is clean and free of debris.

Step 2: Apply Red Loctite to the 1/2" -20 wheel studs and fasten them to the hub. Torque to 60 ft-lbs.



Step 3: With the hub face up, place rotor adapter on the mounting ears with the flat side facing up.

Step 4: Apply Red Loctite to the 7/16-14 x 1” SHCS bolts, torque to 70 ft-lbs



Note: The raised boss of the Rotor Adapter should face down on the hub side as shown below.




Step 5: Place the Rotor with the flat side down on the Rotor Adapter, apply Red Loctite to the 5/16 -18 hex bolts, torque to 18 ft-lbs.



Step 6: Pack inner bearing with grease and insert into back side of hub, Install the 011-6815 rear seal.



Note: Each rotor has directional slots. Before installing you rotor check that you have mounted the correct rotor on the correct side of the vehicle to ensure correct rotation of the slots. See diagram below.



Step 7: For the 2" DROP Wilwood ProSpindle (Part #: 830-9807) use a 29/64th drill bit on the lower mounting ear to drill out the existing threads. Be sure to drill the correct side of the spindle that is opposite to the tierod hole. See below image for reference. NOTE: The standard height Wilwood ProSpindle (Part #: 830-10832) does not need modification.



Step 8: Set the caliper bracket on the spindle and tighten the 7/16-20 FHCS in the upper hole to secure the bracket in place. Insert the 7/16-14 FHCS in the lower hole.



Step 9: Place the aluminum spacer between the steering arm and the mounting ear as shown below. Install the 7/16-14 nylon nut on the end of the bolt and torque to 37ft/lbs. Torque the upper 7/16-20 bolt to 37ft/lbs.



Step 10: Pack outer bearing and install in hub. Slide hub and rotor assembly onto the spindle and secure with the washer, castle nut, and cotter pin.



Step 9: Slide the caliper over the rotor and mount it to the bracket. Snug the 3/8-24 bolts, lock washer, and washer. Check for proper radial and horizontal clearance between the rotor and the caliper.



Step 10: Remove the pad retainer pin (if already inserted). Insert the brake pads from the top of the caliper and reinsert the pad retainer pin. Hold the pads against the caliper housing. Spin the rotor assembly to check for contact between the rotor and brake pads. There should be no contact between the rotor and pads. Be sure to reinstalled the pad retainer pin and clip once pads are installed.



Step 11: If there is pad to rotor contact, determine which side is causing the interference. Shim the caliper or the bracket as needed using the supplied shim kit to center the caliper and ensure the caliper is parallel to the rotor. ****What is required for one side of the car may not be the same as the other side. Check each side individually****

Step 12: Verify the pad material is sitting in the proper location in relation to top of the rotor. [Flush +/- .06"]

Step 13: Go back and torque the caliper mounting hardware to 37 ft-lbs and verify that the bleeder screws are mounted in the top position. (See image below)

Step 14: Connect the brake lines check for interference with any suspension or driveline components. (All caliper fittings are -3AN)

Step 15: Bleed the entire brake system and verify proper caliper operation and release.

If technical support/info is needed, please contact us at (800) 878-9274 or info@tbmbrakes.com

TBM Brakes • 1906 59th Terrace E • Bradenton, FL 34203

Updated: 2/24

WELCOME TO *TEAM TBM*

WE WANNA SEE YOUR *TBM RIDE!*

TAKE SOME PICTURES OF *YOUR BRAKES AND OF YOUR RIDE AND POST THEM UP ON SOCIAL MEDIA*

GIVE US A *FOLLOW AND TAG US ON FACEBOOK & INSTAGRAM*



@TBM BRAKES


**#TEAMTBM
#TBM BRAKES
#WINWITHTBM
#THEBRAKEMAN**



TBM BRAKES

More Info

Caliper Direction: Calipers are labeled -1 and -2 with bleeders and fittings mirrored of each other. These



Acceptable Pad Thickness: Any time pads are $<.100$ " thickness, we advise replacing them.

Rotor Replacement: Our main concern is rotor flatness. This dictates the performance of the rotor. For rotor thickness concerns please reach out to us directly at (800) 878-9274 as rotor thickness varies on each rotor style

Fluid: We recommend using TBM Extreme 6 High Performance DOT 5.1 brake fluid on any and all TBM brakes. This fluid is compatible with Dot 3 and Dot 4 fluid without having to drain your fluid system if you are not able to get your hands on TBM brake fluid. DO NOT ever use DOT 5 brake fluid as it is silicone based and will cause the seals to swell, hindering brake performance and life.

Bearing Grease: If your TBM Brakes utilize a hub that uses greasable bearings, we suggest using any Pre-mium Moly style grease. Our brakes ship with standard Timken bearings which are able to be used with normal bearing grease. Using this grease will still promote our no drag benefits.

Replacement Bearings: We use standard readily available Timken Part Number bearings in our kits to make replacement and servicing easy. In the event you need replacement bearings, use the part numbers listed in the kit instructions for reorder.

Loctite Hardware: We recommend Red Loctite on any and all hardware used in brake applications. Please follow proper procedures in cleaning and drying hardware and surfaces before applying to ensure proper results.

Replacement Hardware: Please note we only sell hardware as complete kits. The hardware kit number listed in the instructions above.

Cleaning Brakes: The unique color and finish on TBM Brakes is an powder coated process that is extremely durable. Cleaning powder coat parts is easiest by using household soap and warm water. Never wash your brakes if they are hot, allow enough cool down time to let the brakes come down to ambient temp.

Caliper Maintenance: Our calipers are engineered, designed, and built to be the most durable calipers on the market. We have customers with over 30 years of abuse on calipers with several reseals and rebuilds throughout. We recommend sending calipers used heavily in every 2 seasons for a cleaning, inspection, and rebuild process. During this time we pressure and leak check the calipers. Any caliper sitting more than 1 year with fluid should be sent in for reseal as seals can become compromised. Please contact us directly to arrange maintenance at (800) 878-9274.

Rotor Maintenance: Over time, pad transfer will build up unevenly on the rotor face. This can result in high spots on the rotor, excessive pad knock-back, inconsistent pedal feel, and/or a decrease in brake torque. It is good practice to routinely clean the pad swept face of the rotors with 80 grit on a dual-action sander or with one of our rotor hones. This can be done as part of a pre-race weekend routine, or something you keep an eye on and work into your mid-season routine. After cleaning the rotor face you will want to follow the bedding procedure to lay a new transfer layer of material down onto the rotor.

Bedding Procedures: When bedding a new set of pads and rotors you are looking to transfer an even layer of pad material onto the rotor. At the drag strip, this can be done by making 2-3 passes and getting on the brakes as you would on any other pass. Getting firmly on the brakes for a second or two to scrub-off speed then off them completely. Get back on them firmly to make the turn, then try your best to come to a stop on the return road without applying a lot of brake. With the rotors hot, coming to a complete stop with a heavy foot can result in high spotting the brake material on the rotors. If trying to bed new pads and rotors away from the racetrack, it is recommended to do so in a safe and controlled environment. Decelerate quickly 4-5 times from roughly 35-50 mph. Trying not to come to a complete stop. Then, decelerate quickly 4-5 times from 50-15 mph. Trying not to come to a complete stop. If the area permits, drive a 1/4 mile dragging the brakes slightly at safe speeds. Then drive an equal distance or more without getting on the brakes, giving the rotors time to cool before coming to a stop. From here, you should notice pad material starting to evenly lay across the pad swept face of the rotor.

Proper Caliper Shimming: Every TBM brake kit comes with several mil-spec shims. These are available to you for a couple of reasons:

- 1.** They can be used to shim the caliper off of the bracket or the bracket off of the spindle in order to get the rotor centered in the caliper. Getting the rotor perfectly centered in the caliper is desired but can be offset slightly inboard or outboard. Making sure the pads fall in the caliper freely and there is no caliper to rotor clearance issues is the most important.
- 2.** The next important use of the shims is to shim the caliper so it is perfectly parallel with the rotor. This may result in having more shims behind one of the fasteners to achieve this.
- 3.** With the potential tolerance stack up across all the components getting mounted to the spindle, it can be common to need to shim the caliper to make it parallel to the rotor. (What might be required on one side of the vehicle may differ on the opposing side.) *This is a critical step. If a caliper is mounted off parallel, the pistons will bind under load, and will not be able to retract properly.

Tip: Once you have the calipers where you think they should be, bleed the brake system. Once bled, loosen the caliper mounting bolts so the caliper can “float”. Apply pressure to the brake pedal and if the caliper moves/ twists, that is where the caliper wants to be under load. It is making itself parallel with the rotor. Shim the caliper off of the mounts so it stays there and tighten everything back up.