


Stair Nosing Insert



Stair Nosing Insert
Flexible insert for fitting to aluminium or brass stair nosing to give a slip-resistant finish.

Dimensions in millimetres and are nominal

Product Attributes

Armstrong Flooring accessories are manufactured under strict quality control from a blend of quality raw materials and are designed to colour co-ordinate with Armstrong resilient flooring ranges and current interior design trends.

Armstrong Flooring - 50mm Stair Nosing Insert

Flexible insert for fitting to aluminium or brass stair nosing to give a slip retardant finish.

50mm Stair Nosing Insert

- Stocked as Black & Flint*
 - Slip retardant
- Available in
- 50mm x 26m coils

*50mm Stair Nosing Insert is stocked in Black & Flint only, additional colour ways are available from "standard" range (MOQ and surcharge applies), *Custom colours are available on request (*MOQ = 5 cartons, 15% surcharge applies), contact your Armstrong Flooring Representative or Customer Services for further information.

Specification

Where noted in the specification and/or schedule of finishes install Armstrong Flooring – 50mm Stair Nosing Insert, colour as specified.

Install Armstrong Flooring - Stair Nosing Insert 50mm to proprietary metal trim, such as aluminium or brass stair nosing or similar as supplied by others (install to manufacturers recommendations).

Armstrong Flooring accessories should be fixed using **Solvent based (Brushable)** contact adhesive (to manufacturers recommendations) refer to [Recommended Adhesives Guide](#).

Installation to AS1884

Substrate

Armstrong Flooring accessories are suitable for installation on most internal building materials (such as concrete, timber, hardboard and rendered surfaces).

Stair Nosing Insert

Inspection of the substrate; it shall be the responsibility of the sub-contractor to thoroughly examine the walls and doors prior to the application of vinyl sheet & accessories.

All surfaces must be dry, clean, smooth, structurally sound and free from moisture, alkali, dust, dirt, wax, oils, grease, loose paint or plaster, or any other foreign matter.

Rectification to imperfections in the surface of the substrate shall be made good prior to fixing vinyl sheet & accessories.

Installation of Armstrong Flooring accessories must conform to **AS 1884**. Special attention should be paid to **AS1884 section 3.1.5 Surface Preparation**.

Fitting

All material should be checked in good natural light for obvious defects prior to fitting; if material has defects immediately contact your supplier.

Install Armstrong Flooring – 50mm Stair Nosing Insert to proprietary metal trim, such as aluminium or brass stair nosing or similar as supplied by others (install to manufacturer's recommendations).

Install using **Solvent Based Contact Adhesive** (to manufacturers recommendations).

[Recommended Adhesives Guide](#)

1. Ensure backing of Stair Nosing Insert is clean and free of dust.
2. Brush or roll (medium nap roller) **Contact Adhesive** on to the Stair Nosing Insert backing (ensuring full coverage).
3. Ensure substrate is clean and free from dust.
4. Using the chalk line as a guide, brush or roll (medium nap roller) **Contact Adhesive** on to the substrate (ensuring full coverage).
5. Allow both surfaces to dry for 10-15 minutes until "touch dry".
6. Ensure the Stair Nosing Insert is positioned correctly and fits neatly to substrate.
7. Using the chalk line as a guide, bring the two components together and bond together by applying pressure with a hand roller over the entire area.

Caution should be taken with **Solvent Based Contact Adhesive**, as this adhesive can be highly flammable.

Maintenance

Damp wiping with a neutral cleaner (e.g. PeerlessJal Versadet) for general maintenance. Solvent-based waxes or ammonia-based cleaners should be avoided.

ALL FLOORCOVERINGS, & ACCESSORIES MANUFACTURED IN AUSTRALIA AFTER 1 JANUARY 1984 DO NOT CONTAIN ASBESTOS

WARNING!

Resilient floorcoverings, adhesives and underlays manufactured in or imported to Australia prior to 1 January 1984 may contain asbestos. If it cannot be definitively established that the previous floor coverings, adhesives and/or underlay do not contain asbestos:

- you should avoid creating dust and should not sand, dry sweep, dry scrape, drill, saw, bead blast or mechanically chip or pulverise the existing floorcoverings, adhesives or underlay, and
- the previous flooring should only be removed by an appropriately licensed asbestos removal contractor.

AU: customerservices@armstrongflooring.au
NZ: customerservices@armstrongflooring.co.nz