


6740 Netherlands Drive Suite D Wilmington, NC 28405







AVANTI 24, 36 or 48 Watchwinder

**INSTRUCTION GUIDE** 

#### Avanti 48 Watchwinder


# Congratulations!

This user guide will help take you through the intial set up and programming of your new watch winder. A majority of fine automatic watches require between 600 and 800 turns per day (TPD), whether worn on your wrist or turning on your watch winder.

# Getting Started - Programmable

### **Turning Power On**

- 1. Carefully unwrap the protective packaging.
- 2. Remove the key that is taped to the glass door.
- 3. Unlock and open the doors.
- 4. Select the programmable setting on each module. (Details below)
- 5. Mount watch on cushion and slide cushion into cup.
- 6. Slide the cup back on to the drive shaft making sure it is fully engaged.
- 7. Turn the power on using master power switch(es) (o/-).




#### Programming Settings (TPD = Turns Per Day) 650 800 1300 1600 950 **OPERATING** MODE TPD TPD **TPD TPD** TPD Clockwise Rotation Only 1 2 3 4 1 2 3 4 Counterclockwise **Rotation Only** 1 2 3 4 Automatic Reversing 1 2 3 4 1 2 3 4 Pause Intervals 31 minutes 25 minutes 21 minutes 15 minutes

## Getting Started - Rotorwind 10/15 Minute Switch

A program switch allows you to select one of two winding cycles: 8 minute (standard program) or 12 minute (extended program). The winding cycle begins every 8 or 12 minutes based on the program selected. Many watches that wind in both directions stay fully wound on the factory preset 8 min. setting.

To set the extended program, remove the mounting cup to reveal the program switch opening. Insert a small object (screwdriver, pencil, etc.) into the opening and slide the switch to the 12 minute setting.

The factory preset is the 8 minute setting.



# Mounting Watch on Cushion

1. With the bracelet or strap of the watch **closed**, squeeze and slide the cushion through the watch. The back of the watch should rest against the Orbita logo and the strap should lie on the flat portion of the cushion.

