


User Guide


Waterproof Fire Chest



Models 1502, 1503 & 1506

Package Includes;


- 1 - Waterproof Fire Chest
- 1 - User Guide
- 2 - Entry Keys



1 Waterproof Fire Chest



1 Operation
Manual



2 Entry Keys

Please carefully check the above list to confirm all items have been received. If any items are missing, please contact Consumer Assistance.

Read this manual carefully and never store it inside the safe!

INDEX

WELCOME / PRODUCT OVERVIEW	PAGE 3
PROPER USE OF YOUR CHEST / HOW TO STORE CHEST / INTERIOR MOISTURE WARNING	PAGE 4
UNLOCKING AND OPENING THE CHEST / CLOSING AND LOCKING	PAGE 5
ORDERING ADDITIONAL KEYS / LOCATING KEY IDENTIFICATION NUMBERS.....	PAGE 6


WELCOME

Your new Honeywell Waterproof Fire Chest will provide years of document and media protection. All Honeywell Waterproof Fire Chests are designed and built using the highest manufacturing standards to ensure maximum user satisfaction under a variety of conditions. Your Honeywell Waterproof Fire Chest will provide peace of mind for many years to come.

Thank you and enjoy!

PRODUCT OVERVIEW

- A - Chest Lid
- B - Lock Assembly
- C - Chest Body
- D - Handle
- E - Lock Cylinder



PROPER USE

Honeywell Waterproof Fire Chests are designed to protect paper documents and files from heat and moisture damage due to exposure to fire and water.

IMPORTANT: Before using your new chest it should be opened and aired out for at least 30 minutes to allow the waterproof seal to decompress and perform as intended.

WARNING: This chest is not intended for the storage of medications, firearms, ammunition, or combustible items of any kind.

WARNING: You should not store pearls in this chest because they may sustain damage at temperatures below 350 ° F.

Fire Protection


Independent testing verified the interior temperature remains below 350° F (177°C) for thirty minutes when outside temperature is up to 1550°F (843°C).

Water Protection

Independent testing verified that the interior remains dry when completely submerged for up 72 hours.

HOW TO STORE CHEST

For your chest to perform as specified, it must always be stored flat with the lid on top. Never store the chest on any of the sides or upside-down.



RIGHT



WRONG

INTERIOR MOISTURE WARNING

IMPORTANT: For optimum performance, Waterproof Fire Chests should be opened and aired out for at least 30 minutes every week to prevent any build up of moisture inside. It is recommended to occasionally do this for longer periods. This will balance the humidity difference inside and outside and allow any excess moisture trapped inside to escape. If you do not open Waterproof Fire Chests on a regular basis to let them air out, you may begin to notice a musty smell, especially on paperwork. The manufacturer will not be responsible for any damage or loss of items placed in Waterproof Fire Chests due to moisture. Proper care and preventative maintenance of Waterproof Fire Chests is the owner's responsibility. The owner should understand that this is required to assure continued levels of protection and trouble-free performance during the lifetime.

UNLOCKING AND OPENING THE CHEST

1. Insert key into lock cylinder (Figure 1).
2. Press down firmly on top of chest and turn the key clockwise to the right $\frac{1}{4}$ turn (Figure 2).
3. The Chest is now unlocked and you may lift the lid (Figure 3).




Figure 1




Figure 2




Figure 3



WARNING:

To avoid possible injury, make sure hands or fingers are clear before closing the chest lid.

CLOSING AND LOCKING THE CHEST

WARNING: To avoid possible injury, make sure hands or fingers are clear before closing the chest lid.

1. Carefully lower lid into the closed position (Figure 1).
2. Insert key into lock cylinder (Figure 2).
3. Press down firmly on top of chest and turn the key counter clockwise to the left $\frac{1}{4}$ turn (Figure 3).
4. The Chest is now locked and you may remove the key.




Figure 1




Figure 2




Figure 3

ORDERING ADDITIONAL KEYS

The following information is required to order keys:

1. PROOF OF OWNERSHIP (1 of 2 Options Below)

A) SALES RECEIPT & IDENTIFICATION – (INTERNATIONAL ORDERS ONLY!)

- Copy of sales receipt showing Store, Date & Product Description.
- Copy of your picture I.D. (Drivers license, passport, regular I.D.).

B) PRODUCT OWNERSHIP VERIFICATION FORM

If sales receipt is not available, contact us by email or telephone to request a “Product Ownership Verification Form”.

2. ORDER INFORMATION

CONTACT:

- Name & Shipping Address
- E-mail address (If Available)
- Telephone Number
- Best Time to Contact You

PRODUCT:

- Safe Model #
- Lock Key #
- Quantity of Keys Ordered

3. PLACING AN ORDER

- To begin the order process, contact us by telephone, email, or mail

4. METHOD OF PAYMENT

- Visa, MasterCard, Check or Money Order

NOTE: For pricing please contact Consumer Assistance. Contact information is located on page 5 of this manual. Payment method and pricing subject to change.

LOCATING KEY IDENTIFICATION NUMBERS

Key Number

3-4 digit number etched on the metal collar located around the key hole (Figure 1). This same 3-4 digit number is also etched on the key itself (Figure 2).




Figure 1




Figure 2