

# MONRIDE EBIKE SETUP

1. Remove eBike from box and remove all packaging materials.
2. Install the handlebar by rotating the stem counter clockwise. The brake cable must be on the left and make sure no cables are wrapped around the head tube. Use a 5mm Allen wrench to loosen the handlebar adjustment bolt and adjust it and tighten it. Place the handle bar on the stem and use a 4mm Allen wrench to tighten the 4 bolts.
3. To install the front wheel, remove the quick release and skewer and pass the skewer through the hub from the brake rotor side of the wheel. Reinstall the springs and should point in towards the wheel hub. Lift the front of the eBike and lower the fork onto the wheel and tighten the quick release.
4. Open the Kickstand and stand the eBike up. Check all bolts and fastening with the included tool.
5. Install front fender and headlight. Remove screw from back of fork, place fender and then replace screw to hold fender and light in place. Unbolt the fender mounts on each side and wrap the mounts onto the fork and tighten the clamp bolts. Ensure the fender is evenly installed.
6. Remove the seat post, add some grease to the post and reinsert the post to your desired position and tighten the clamp.
7. Install each pedal on the right or left side as per the pedal R or L sticker. Remove sticker, use 15mm wrench included. Left pedal is a reverse thread for tightening.
8. Inspect the tires and inflate as indicated on the tire sidewall.
9. Charge your battery BEFORE the very first use.
10. Remove the battery key BEFORE the very first use.
11. Remove the lock key (Somered and Monkland only) BEFORE the very first use.

NB: Download the MONRIDE User Manual at [monride.com](http://monride.com) to carefully understand the workings and performance of your MONRIDE eBike. For your safety, please wear a helmet.