





PJAMA BEDWETTING ALARM



BUTTON DIAGRAM AND FEATURES ALARM UNIT

	Volume
	On/Off
	Select sound





INSTRUCTION


For best results: The child should be motivated and want to get dry. The parent needs to help the child to wake up, especially at the beginning of the treatment.

NOTE: Charge the alarm unit before use. Use the supplied USB cable. The sensor does not need to be charged and is already paired with the alarm unit.


Charging via:	Time - fully charged
Computer	4-6 hours
AC Adapter 5V 1.0A	3 hours

During charging, a red LED light flashes. When charging is complete, the red LED light will light constantly.

1. Turn on the alarm by pressing the  button. A red LED flashes next to the  on button and you will hear a sound indicating that the alarm is activated.
2. Press the  button and select one of the seven different alarm sounds. The last played sound will be the sound alarming.
3. Adjust the volume with the  button.

4. Place the alarm unit in the desired location in the room. To test the alarm unit, short the contacts on the sensor using a metal object (see picture below). Range of alarm about 10m.
5. Attach the sensor to the buttons located in the pocket on the inside of the Pjama pants. Make sure it is securely fastened. The alarm is now ready to use.
6. Press the  button to turn off the alarm.
7. Unplug the sensor from Pjama pants when the alarm is not being used or when the Pjama pants are to be washed. Wipe of the sensor if it is wet.
8. The red LED flashes faster when the device needs charging.

For more information, see www.pjamastore.com/product-manuals



Short-circuit the contacts on the sensor using a metal object such as scissors.

WARRANTY

The Pjama bedwetting alarm has a one-year warranty from the buyer's date of the alarm. You must be the original buyer and show evidence of your purchase. This warranty does not apply if caused by an accident or similar incident or injury, water damage, negligence, abnormal use or failure to comply with the instructions in this manual.

CAUTION

- Children age five and older, or as recommended by a physician.
- Pjama Bedwetting Alarm is intended for use as an enuresis alarm. Make sure that no parts of the Pjama Bedwetting Alarm are put in the mouth for any reason. This could cause choking or other harm.
- The Pjama Bedwetting Alarm is a medical device it should be treated as such, with care.
- Do not hold an alarming speaker within 4 inches (10 cm) of the ear. This could cause damage to the ear.
- Do not charge speaker unit during night or when not home.
- To extend battery life, disconnect sensor from pants when not being used.

FCC WARNING

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

