# GENERATION LIGHTING

WALL

#### **GENERAL PRODUCT INFORMATION:**

These fixtures are intended to be installed utilizing NEC compliant junction boxes.

This product is safety listed for damp locations.

Incandescent version may be dimmed with a standard incandescent dimmer. LED version may be dimmed with a LED dimmer. Consult lamp manufacturer for additional information.


This instruction shows a typical installation.

#### **CAUTION - RISK OF FIRE**


This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Use minimum 90°c supply conductors.

### **SAVE THESE INSTRUCTIONS!**



## **Install the Fixture**



- Secure the mounting plate to the junction box.
- Install the shade by aligning the holes on the shade with the holes on both plates, then secure in place using the plate screws.
- 3 Screw the lamp into the socket. Refer to the label on the lamp socket for Max Wattage Information.
- 4 Connect the fixture to a suitable ground in accordance to local electrical codes.
- 5 Connect the white fixture wire (square and/or rigid) to the neutral power line wire with a wire nut.
- 6 Connect the black fixture wire (round and/or smooth) to the hot power line wire with a wire nut.
- Neatly place all the wires into the junction box, place the fixture base onto the mounting plate, and secure it in place using the set screw and Allen wrench.
- Adjust the angle of the shade by gently tilting it up and down.
- 9 Model AEW1002 Only: The fixture arms can rotate in a 142° arc to help with positioning the light.